



# use & care guide



## UNDERCOUNTER DISHWASHER

Model DU1098XR Series

Freezers, Refrigerator-Freezers, Ice Makers, Dishwashers, Built-In Ovens, and Surface Units, Ranges, Microwave Ovens, Trash Compactors, Room Air Conditioners, Dehumidifier




304274

# Contents

|  | Page |   | Page |
|--|------|---|------|
| <b>BEFORE YOU USE YOUR DISHWASHER</b> ..   | 2    | WASH Cycle .....                            | 9    |
| <b>IMPORTANT SAFETY INSTRUCTIONS</b> ..... | 2    | HEAT DRY or AIR DRY .....                   | 9    |
| <b>PARTS AND FEATURES</b> .....            | 3    | To Add a Dish After Starting .....          | 9    |
| <b>FOR BEST RESULTS</b> .....              | 4    | <b>ENERGY SAVING TIPS</b> .....             | 10   |
| The Filtering System .....                 | 4    | <b>SPECIAL TIPS</b> .....                   | 11   |
| Quiet Operating Tips .....                 | 4    | <b>COMMON DISHWASHING PROBLEMS</b> ..       | 12   |
| <b>PROPER LOADING</b> .....                | 5    | <b>IF YOU NEED SERVICE OR ASSISTANCE</b> .. | 14   |
| Top Rack Loading .....                     | 5    | 1. Before Calling For Assistance .....      | 14   |
| Bottom Rack Loading .....                  | 6    | 2. If You Need Assistance .....             | 15   |
| Silverware Basket Loading .....            | 6    | 3. If You Need Service .....                | 15   |
| <b>ADDING DETERGENT</b> .....              | 7    | 4. If You Have a Problem .....              | 15   |
| <b>BEFORE STARTING YOUR DISHWASHER</b> ..  | 8    |   |      |
| <b>STARTING YOUR DISHWASHER</b> .....      | 8    |   |      |

©1986 Whirlpool Corporation

## Before you use your dishwasher



**It is your personal responsibility and obligation to be sure your dishwasher:**

- Is installed by a qualified installer.
- Has been installed where it is protected from the elements.
- Has been installed on a floor strong enough to support its weight.
- Has been properly connected to electricity, water and drain.\*
- Has been properly electrically grounded.\*
- Is not used by children or anyone unable to operate it properly.
- Is properly maintained.

\*See installation instructions for complete information.

## Important safety instructions



**WARNING** – When using your dishwasher, follow basic precautions, including the following:


1. Read all instructions before using the dishwasher.
2. **DO NOT** let children play in or on the dishwasher.
3. **DO NOT** reach into the area below the bottom rack until the Heating Element has cooled for at least 20 minutes.
4. **DO NOT** wash plastic items unless marked "Dishwasher Safe" or the equivalent. If not marked check manufacturer's recommendations.
5. Store dishwasher detergent in a cool, dry place WHERE CHILDREN CAN'T REACH IT.
6. Use **ONLY** detergents and rinse aids recommended for use in a dishwasher.
7. **REMEMBER**, use your dishwasher only for the job it was designed to do.
8. Locate sharp items and knives so that they are not likely to damage door seal or cut the user.
9. Properly connect to electricity and water.
10. **DISHWASHER MUST BE ELECTRICALLY GROUNDED.** Read the Installation Instructions for details.
11. **DO NOT** use your dishwasher unless all enclosure panels are properly in place.
12. Be sure your dishwasher is installed on a level floor that will hold the weight, and in an area suitable for its size and use.
13. **DO NOT** sit or stand on or abuse the dishwasher door or dish racks.
14. **DO NOT** tamper with controls.
15. When discarding an old dishwasher, always remove the door to prevent accidental entrapment.
16. **WARNING:** If hot water has not been used recently (usually two weeks or longer), hydrogen gases may build up in the water heater and the hot water pipes. **HYDROGEN GAS IS EXPLOSIVE.** To prevent injury or damage, before using your dishwasher, turn on all hot water faucets and allow water to run for several minutes. This will allow gases to escape. Do not smoke or use any open flame near the faucet while it is open.
17. **WARNING:** Disconnect electrical power to the dishwasher before attempting to service.

— SAVE THESE INSTRUCTIONS —

# Parts and features

## Model DU098XR Series

BEFORE YOU USE • SAFETY • PARTS AND FEATURES



### Copy your Model and Serial Numbers here...

When you need service or call with a question, have this information ready:

1. **Complete** Model and Serial Numbers (from the plate located as shown).
2. Purchase date from sales slip.

Copy this information in these spaces. Keep this book, your warranty and sales slip together in a handy place.

**Please complete and mail the Owner Registration Card furnished with this product.**

Model Number \_\_\_\_\_


Serial Number \_\_\_\_\_

Purchase Date \_\_\_\_\_


Service Company and Telephone Number \_\_\_\_\_

# For Best Results

Your dishwasher cleans by spraying a mixture of hot, clean water and detergent against soiled surfaces of dishes. When a cycle is started, the dishwasher fills with water to about the level of the heating element. This water is pumped through the rotating spray arms, drained through the filter system which removes food and soil, and pumped back through the rotating spray arms. Soiled water is pumped out and replaced with clean water during a cycle – the number of times depends on the cycle being used.



The self-cleaning filtering system and removable pump guard help eliminate pre-rinsing by removing food particles from the water.



Load dishes so soiled surfaces face powerful spray from rotating arms.

## The filtering system


It is not necessary to rinse dishes before putting them into the dishwasher. Just remove large pieces and quantities of food and bones. The filtering system helps keep food particles out of the wash water. Small particles are flushed away as water is pumped out. Larger particles are trapped in the pump guard.

To remove the pump guard for cleaning...

1. Wait at least 20 minutes after a cycle for the heating element to cool down.
2. Unload and remove the bottom rack.
3. Press the outside wall of the pump guard at the center to release the latch.
4. Lift out and rinse clean.

To replace the pump guard...

1. Insert pump guard legs (on inside wall) into matching openings in filter screen.
2. Press down on outside wall until latch snaps into place.
3. Replace bottom rack with rack bumpers in front.



Check Water Temperature

## Water must be hot

For best cleaning and drying results, water should be at least 140°F (60°C).

1. Turn on hot water faucet nearest the dishwasher. Let water run until it is as hot as possible.
2. Hold a candy or meat thermometer in the stream of hot water to measure the temperature.
3. If the temperature is too low, have a qualified person raise the water heater thermostat setting.

## Quiet operating tips

To avoid thumping and clattering noises during operation:

- Make sure light weight load items are secured in the rack.
- Make sure pot lids and handles, pizza pans, cookie sheets, etc. do not touch interior walls



or interfere with either of the spray arms rotation.

- Load dishes so they **don't** touch one another.
- NOTE: Keep sink drain plugs inserted during dishwasher operation to prevent noise transfer through drains.**

# Proper loading

Always load dishes so soiled surfaces are reached by spray from rotating spray arms. Water must be able to drain off completely for best drying results. Be careful to separate items so spray can reach all surfaces.


## Top rack loading




The top rack is designed for cups, glasses and smaller items.

- Place so open ends face down for cleaning and draining.
- **Load glasses in top rack only.** Bottom rack is not designed for glasses. Damage may occur.

- Place items in the rows **between** prongs. Placing them **over** the prongs can lead to breakage.
- Be sure lightweight items are held firmly in place.
- China, crystal and other delicate items must not touch each other during dishwasher operation. Damage may occur.




- Load plastic items **only in the top rack.** Only plastic items marked "dishwasher safe" are recommended.
- Plastic items can be melted in the bottom rack.




- Small bowls, pans and other utensils can be placed in the top rack.

Items with cooked-on or dried-on foods should be loaded in the bottom rack with soiled surfaces facing the spray.

## Bottom rack loading




- Make sure pot handles and other items do not stop rotation of either the upper or lower spray arm. Spray arms must move freely.
- Securely place heavily soiled cookware face down in rack.




- Place plates, soup bowls, etc., **between** prongs and facing the spray.


## Silverware basket loading



- Load cookie sheets, cake pans and other large items at sides and back. Loading such items in front may keep water spray from reaching detergent dispenser.



Load the silverware basket while it's in or out of the bottom rack. The loaded basket should be in the right front corner of the bottom rack.



Load forks and spoons so they **don't nest together**. Spray can't reach nested items.

Mix items in each section of the basket with some pointing up and some down.

Small items – baby bottle caps, jar lids, etc. – can be put in any section.



Make sure sharp items (knives, forks, skewers, etc.) are put in point down. Make sure long items do not stop the upper spray arm from turning.

### NOTE:

- Do not load glasses, cups or plastic items in the bottom rack.
- When lower rack is removed, replace with bumpers in front.

# Adding detergent

The kind and amount of dishwasher detergent you use is an important part of getting your dishes clean. Read this section carefully.



## Use automatic dishwasher detergent only.

Other detergents are too mild and much too soapy to work in the dishwasher.

Different brands of dishwasher detergent have different amounts of phosphorus. Phosphorus softens water and helps prevent water spots on dishes.

If water is hard and phosphorus content is low (8.7% or less), you may need to use more detergent or use a brand with a higher phosphorus content (12% or higher).

Do not add detergent until you are ready to wash. **Fresh automatic dishwasher detergent is necessary for best washing results.** Store detergent tightly in a cool dry place.





## The detergent dispenser

The detergent dispenser has one section with a cover and one without.

- Put detergent in both sections.
- Push the cover down until it is latched.


The cover opens automatically when the main wash starts. Detergent in the open section falls into the dishwasher when the door is closed.




## How much detergent to use

The amount of detergent to use depends on the hardness of your water. If too little is used, dishes won't be clean. However, if too much is used in soft water, glassware will begin to etch.

Find out your water's hardness by asking your local water department, water softener company or county extension agent.



- **HARD** – Fill 1 or both sections to top line if water is 8 or more grains of hardness.
- **MEDIUM** – Fill 1 or both sections to middle line if water is 5 to 7 grains of hardness.
- **SOFT** – Fill 1 or both sections to bottom line if water is 0 to 4 grains of hardness.




**DRY SELECTOR SWITCH**

## Before starting your dishwasher

1. Spin the Upper Spray Arm to make sure nothing will stop it from turning freely.
2. Push door firmly when closing and it will automatically latch.
3. Run hot water at sink nearest dishwasher until it is hot. Turn it off.


## Starting your dishwasher



### **WASH cycle...**


1. Select a drying option.
2. Make sure the Cycle Control Knob points to dot marked **START**.
3. Without turning it, pull the Cycle Control Knob out to start the Cycle.





### WASH Cycle

A double wash for normal to heavily soiled loads. (The Energy Guide Label data is based on this cycle.) Cycle time is about 60 minutes.



### HEAT DRY or AIR DRY?

If the **HEAT DRY Option** is selected air in the dishwasher is heated during the "dry" part of the cycle.

If the **AIR DRY Option** is selected, air in the dishwasher is not heated. The Cycle Control Knob will keep moving clockwise until the "dry" part of the cycle is complete.

Using the **AIR DRY Option** helps save energy, but dishes take longer to dry (overnight) and some water spotting may result. Some items (such as plastics) may need towel drying.


For best results, use a solid rinse aid.

### To add a dish after starting


1. To be sure the added item is washed and rinsed, make sure the Cycle Control Knob has not passed WASH.
2. Unlatch the door to stop the cycle.
3. Open the door and add the dish.
4. Close the door. **Do not latch it.** Wait 30 seconds for air in the dishwasher to warm up. This helps reduce the amount of moisture that can come from the vent when restarting the cycle.
5. Latch the door. The dishwasher will start from where it stopped.

# Energy saving tips


You can help save energy if you:




**1. Wash full loads.** Running a half-filled dishwasher uses the same amount of electricity and hot water as a fully loaded machine.




**2. Air dry dishes** when you don't need a rapid drying cycle. Allow longer drying times (overnight).



**3. Load correctly** for best washing results. Incorrect loading may cause poor washing and the need to rewash all or part of the load.



**4. Don't pre-rinse normally soiled dishes.** Using the WASH Cycle with the recommended amount of detergent and proper loading will provide good washing results without hand rinsing.



**5. Use your dishwasher** during off-peak hours. Local utilities recommend this to avoid heavy usage of energy at certain times of day.

**6. Kitchen cleanup** can be done quickly and efficiently through the use of your dishwasher. Most appliance parts that can fit in the dishwasher can be cleaned by it. Burned-on soil, however, should be cleaned by hand.

# Special tips on dishwasher use

**Remember, use your dishwasher only for the job it was designed to do.**

**Some items are not dishwasher safe or may require special care.**

**Read these special tips for the following items:**

**Aluminum:** Aluminum loses its bright, shiny appearance and darkens in color due to minerals in the water and the alkalinity of the dishwasher detergent. Colored aluminum may fade.

**TIPS:** If washed in the dishwasher avoid placing directly in front of detergent dispenser where it could be sprinkled with undissolved detergent, causing spotting, pitting, and discoloration. Follow utensil manufacturers' cleaning instructions.

**China:** Hand-painted, metal-trimmed, and antique china may fade due to high water temperatures and alkaline detergent solution in the dishwasher.

**TIPS: Delicate, antique items should not be washed in the dishwasher.** Load carefully. Do not allow pieces to touch each other. Test one piece by washing it daily in the dishwasher for several weeks. Then compare it with the rest of the set to see if colors have changed.

**Crystal and decorative glasses:** Crystal can break from sudden exposure to high water temperature. Metal trim and colorful decoration on glass will fade in time when washed in the dishwasher.

**TIPS: Delicate, antique items should not be washed in the dishwasher.** Load carefully in **top rack only**. Be sure to load a few larger items in the bottom rack to reduce amount of force of water spray reaching glassware from lower spray arm. Use the shortest cycle.

**Flatware:** Salty and acidic foods may tarnish silver and stainless flatware if allowed to remain on the utensils. A film may form on sterling silver and silver plate items washed in a dishwasher. This film is caused by reaction of silver with chlorine in the detergent. **Gold flatware is not dishwasher safe.**

**TIPS:** Rinse flatware as soon as possible, especially if it is not to be washed right away. Dishwasher detergent may remove antique finishes. Wash by hand. Tarnish and film build-up can be removed with silver polish.

**Cast iron utensils:** The seasoned finish will be removed in the dishwasher. Rusting will result.

**TIPS:** Wash by hand. To re-season, coat with unsalted fat and heat in a slow oven for an hour or two.

**Plastics:** Many plastics will have "Dishwasher Safe" written on them. Some plastics are heat sensitive and may melt or warp.

**TIPS:** If in doubt, try one piece. Place in upper rack only. AIR DRY option provides additional protection.

**Non-stick finish utensils:** Most can be washed in the dishwasher.

**TIPS:** Follow manufacturers' suggestions.

**Wood:** Many wooden items will crack and warp or lose their finish.

**TIPS: Do not wash cutting boards, wooden salad bowls or knives with wooden handles in the dishwasher.**


**Pewter or pewter-like materials:** May streak, discolor, and pit.

**TIPS:** To keep pewter at its very best, hand wash with mild detergent.

## Dishwasher care & cleaning:

**Exterior** – Regular use of a soft damp cloth or sponge and a mild detergent is all that is necessary, in most cases, to keep the outside of your dishwasher nice looking and clean. **Interior** – Hard water minerals may cause a white film to build-up on the inside surfaces, especially just beneath the door area.

Wear rubber gloves when cleaning the dishwasher interior. **Do not use any type of cleanser other than dishwasher detergent because it may cause foaming or sudsing.**



# Common dishwashing problems

| PROBLEM  | CAUSED BY  | SOLUTION  |  |
|--|--|---|--|
| <b>Spotting and filming</b><br>(hard water film) | Hard water   | Fill detergent dispensers to capacity. Use dishwasher detergent with highest available phosphorus content. May be necessary to install water softener.<br><br>To remove spots and film, try a vinegar rinse...<br>1. Wash and rinse load as usual. Use AIR DRY.<br>2. Remove all metal items.<br>3. Put 2 cups (500 mL) white vinegar in a container on the bottom rack.<br>4. Run dishwasher through a complete washing cycle. |  |
|  | Water is not hot enough  | Water temperature should be at least 140°F (60°C). Set water heater thermostat to a higher setting. Run water at sink until hot before starting.  |  |
|  | Not enough detergent, or improper detergent<br>"Old" detergent | Use more dishwasher detergent. Use detergent with highest available phosphorus content...especially with hard water.<br><br>Use only fresh dishwasher detergent. Store <b>tightly closed</b> container, in cool, dry place. Discard old detergent. Do not fill dispensers until ready to start dishwasher.  |  |
|  | Improper loading   | Make sure dishes and glassware are loaded so spray reaches all surfaces and items drain properly. Do not overload. Do not nest items.<br><br>Make sure large items do not block spray from reaching detergent dispensers.   |  |
|  | No rinse aid   | Try a bar rinse aid such as Solid Jet DRY®. Follow package directions.  |  |
|  | AIR DRY Setting used   | Drying without heat may result in some spotting of glasses and silver.  |  |
| <b>Small particles deposited on items</b>        | Spray arm or arms not rotating freely<br>"Old" detergent       | Check spray arms to make sure they turn freely after loading. Be sure a utensil has not prevented their turning.<br><br>Use only fresh dishwasher detergent. Store <b>tightly closed</b> container, in cool, dry place. Discard old detergent. Do not fill dispensers until ready to start dishwasher.  |  |
|  | Not enough detergent, or improper detergent                    | Use more dishwasher detergent. Use detergent with highest available phosphorus content...especially with hard water.  |  |
|  | Water is not hot enough  | Water temperature should be at least 140°F (60°C). Set water heater thermostat to a higher setting. Run water at sink until hot before starting.  |  |
|  | Water pressure may be low, dishwasher is not filling properly  | If water pressure is low, do not use water for other purposes while dishwasher is running (to assure correct fills).  |  |
|  | <b>Dishes not dry</b>  | Water is not hot enough   | Water temperature should be at least 140°F (60°C). Set water heater thermostat to a higher setting. Run water at sink until hot before starting. |
|  |  | Improper loading  | Make sure dishes and glassware are loaded so spray reaches all surfaces and items drain properly. Do not overload. Do not nest items.            |
| No rinse aid                                     |  | Fill rinse aid dispenser.   |  |
| AIR DRY Setting used                             |  | Allow more time when using AIR DRY Option, or use HEAT DRY. Plastic items may need towel drying.  |  |
| <b>Black marks on dishes</b>                     | Aluminum utensils rubbing against items during washing         | <b>Use care in loading aluminum utensils, especially any lightweight foil container. Place so they do not touch dishes.</b> Remove black marks with plastic scouring pad and a mild abrasive cleanser.  |  |
| <b>Chipping or breaking glassware</b>            | Improper loading   | Do not overload. Load glasses in the top rack only. Load between prongs, not over them. Glasses loaded over prongs will not be supported and may chip or break.   |  |

| PROBLEM   | CAUSED BY  | SOLUTION  |
|---|--|---|
| <b>Dishes not washing clean</b>   | Water is not hot enough  | Water temperature should be at least 140°F (60°C). Set water heater thermostat to a higher setting. Run water at sink until hot before starting.<br>Option.   |
|   | Improper loading   | Make sure dishes and glassware are loaded so spray reaches all surfaces and items drain properly. Do not overload. Do not nest items.<br>Make sure large items do not block spray from reaching detergent dispensers.   |
|   | Spray arm or arms not rotating freely  | Check spray arms to make sure they turn freely after loading. Be sure a utensil has not prevented their turning.  |
|   | Not enough detergent or improper detergent<br>"Old" detergent.   | Use more dishwasher detergent. Use detergent with highest available phosphorus content...especially with hard water.<br>Use only fresh dishwasher detergent. Store <b>tightly-closed</b> container, in cool, dry place. Discard old detergent. Do not fill dispensers until ready to start dishwasher.  |
| <b>Cloudy film on glassware, etching – permanent corrosion</b>  | Water pressure may be low, dishwasher is not filling properly  | If water pressure is low, do not use water for other purposes while dishwasher is running (to assure correct fills).  |
|   | Too much detergent in soft water   | Check for rainbow hue on glasses. A rainbow hue is the first sign of etching (corrosion of glass). Reduce the amount of dishwasher detergent. Use a detergent with a lower phosphorus content.  |
|   | Inadequate rinsing   | If water pressure is low do not use water for other purposes while dishwasher is running (to assure correct water fills). Make sure dishes and glassware are loaded properly to assure adequate rinsing and draining. Do not overload.  |
| <b>Dishes &amp; interior of dishwasher yellow or brown</b>  | Iron or manganese in water   | <b>Temporary remedy:</b><br>1. Start dishwasher and unlatch door to stop it when it has filled for the wash part of the cycle.<br>2. Add ¼ to ½ cup (120 to 240 mL) of citric acid crystals (usually available in drugstores).<br>3. Close and latch door to complete cycle.<br><b>Permanent solution:</b> Install an iron or manganese filter to home water supply.  |
|   |  |   |
| <b>Rust spots on stainless steel -OR- Dark spots on flatware – stainless steel, silver plate, or sterling</b> | Allowing salty or acidic foods such as mayonnaise, vinegar, fruit juices, salad dressings, milk products to remain on flatware.<br>Undissolved detergent coming in contact with flatware | Rinse flatware that is to stand for several hours before washing. Clean stained items with silver polish and re-wash. <b>Do not put stainless steel and silver flatware in the same silverware basket compartment. Direct contact between these metals can cause permanent damage to the silver.</b><br><br>Remove spots with silver polish. Avoid spilling concentrated detergent on wet flatware.   |
|   |  |   |
| <b>Bronze tarnish on silverplate</b>  | Silverplate is worn off. Exposed base metal takes on a bronzed hue.  | Remove tarnish with silver polish. Have silver replated.  |
| <b>Water left in bottom of dishwasher</b>   | Dishwasher cycle not completed   | Allow dishwasher to complete cycle.   |
|   | Clogged drain air gap  | Some plumbing codes require use of a drain air gap between an <b>undercounter</b> dishwasher and the drain system of the house. The air gap is usually located above the sink or on the top of the counter near the dishwasher to prevent the possibility of water backing up from the drain into the dishwasher due to a plugged drain. The drain air gap is <b>NOT</b> a part of the dishwasher and is <b>NOT</b> covered by the dishwasher warranty. The drain air gap should be kept clean to insure proper draining of the dishwasher. |


# If you need service or assistance, we suggest you follow these four steps:

## **1. Before calling for assistance...**

Performance problems often result from little things you can find and fix yourself without tools of any kind.




- Have you checked your home's main fuses or circuit breaker box?



### **If your dishwasher will not run, or stops during a cycle:**

- Is the door tightly closed and securely latched?
- Has the cycle been correctly set (and the Control Knob pulled out)?



- Is the dishwasher wired into a live circuit with the proper voltage (undercounter models)?
- If the motor has stopped because of an overload, it will automatically reset itself within a few minutes. If the motor does not start, call for service.

### **If water remains in the dishwasher:**

- Has the cycle completed?
- A small amount of remaining water is normal.
- Is drain air gap clogged?

### **If detergent remains in the covered detergent cup:**

- Is the bottom rack in backwards? (The rack bumpers should be at the front.)
- Is the dishwasher detergent fresh?
- Is the cycle completed?

- Is the water turned on?

## 2. If you need assistance\*...

Call Whirlpool COOL-LINE® service assistance telephone number. Dial free from:

**Continental U.S.** ..... (800) 253-1301  
**Michigan** ..... (800) 632-2243  
**Alaska & Hawaii** ..... (800) 253-1121

and talk with one of our trained Consultants. The Consultant can instruct you in how to obtain satisfactory operation from your appliance or, if service is necessary, recommend a qualified service company in your area.



FSP is a registered trademark of Whirlpool Corporation for quality parts. Look for this symbol of quality whenever you need a replacement part for your Whirlpool appliance. FSP replacement parts

will fit right and work right, because they are made to the same exacting specifications used to build every new Whirlpool appliance.



## 3. If you need service\*...

Whirlpool has a nationwide network of franchised TECH-CARE® Service Companies. TECH-CARE service technicians are trained to fulfill the product warranty and provide after-warranty service,

anywhere in the United States. To locate TECH-CARE service in your area, call our COOL-LINE service assistance telephone number (see Step 2) or look in your telephone directory Yellow Pages under:

APPLIANCES - HOUSEHOLD - MAJOR - SERVICE & REPAIR

ELECTRICAL APPLIANCES - MAJOR - REPAIRING & PARTS

OR

WHIRLPOOL APPLIANCES FRANCHISED TECH-CARE SERVICE

WHIRLPOOL APPLIANCES FRANCHISED TECH-CARE SERVICE

SERVICE COMPANIES

SERVICE COMPANIES

XYZ SERVICE CO  
123 MAPLE ..... 999-9999

XYZ SERVICE CO  
123 MAPLE ..... 999-9999

OR

WASHING MACHINES, DRYERS & IRONERS - SERVICING

WHIRLPOOL APPLIANCES FRANCHISED TECH-CARE SERVICE

SERVICE COMPANIES

XYZ SERVICE CO  
123 MAPLE ..... 999-9999

## 4. If you have a problem\*...

Call our COOL-LINE service assistance telephone number (see Step 2) and talk with one of our Consultants, or if you prefer, write to:

Mr. Robert Stanley  
 Division Vice President  
 Whirlpool Corporation  
 2000 US-33, North  
 Benton Harbor, MI 49022

\*If you must call or write, please provide: model number, serial number, date of purchase, and a complete description of the problem. This information is needed in order to better respond to your request for assistance.



Making your world a little easier.

Part No. 304274 Rev. A  
©1986 Whirlpool Corporation

Printed in U.S.A.

Makers. Dishwashers, Built-In Ovens, and Surface Units, Ranges, Microwave Ovens, Trash Compactors, Room Air Conditioners, Dehumidifiers, Automatic Washers, Clothes Dryers

