


# use & care guide



  
**Whirlpool**

**ELECTRIC  
RANGE**  
Model RF3000XP

Wave Ovens, Trash Compactors, Room Air Conditioners, Dehumidifiers, Automatic Washers, Clothes Dryers, Freezers, Refrigerator-Freezers



# Contents

	Page		Page
<b>Before You Use Your Range</b> . . . . .	2	<b>Caring for Your Range</b> . . . . .	10
<b>Important Safety Instructions</b> . . . . .	3	Control Panel . . . . .	10
<b>Parts and Features</b> . . . . .	4	Surface Units and Reflector Bowls . . . . .	11
<b>Using Your Range</b> . . . . .	5	Lift-Up Cooktop . . . . .	12
Using the Surface Units . . . . .	5	Oven Door . . . . .	13
Optional Canning Kit . . . . .	6	Lower Panel . . . . .	13
Using the Oven Controls . . . . .	6	Cleaning Chart . . . . .	14
Baking . . . . .	6	<b>If You Need Service or Assistance</b> . . . . .	14
Broiling . . . . .	8		
Oven Vent . . . . .	10		
Optional Rotisserie . . . . .	10		

© 1984 Whirlpool Corporation

## Before you use your range

**Read this Use & Care Guide and The Cooking Guide for important safety information.**

### **You are personally responsible for:**

- Reading and following all safety precautions in this Use & Care Guide and the Cooking Guide.
- Installing the range where it is protected from the elements, and on a floor strong enough to support its weight.
- Properly connecting the range to electrical supply and grounding. (See "Installation Instructions.")
- Making sure the range is not used by anyone unable to operate it properly.
- Properly maintaining the range.
- Using the range only for jobs expected of a home range.

**See "Cooking Guide" for important safety and use information.**

# IMPORTANT SAFETY INSTRUCTIONS



**WARNING** – When using your range, follow basic precautions, including the following:

- 1. DO NOT** allow children to use or play with any part of the range, or leave them unattended near it. They could be burned or injured.
- 2. DO NOT** store things children might want above the range. Children could be burned or injured while climbing on it.
- 3. DO NOT** allow anyone to touch hot surface units or heating elements. Dark colored units and elements can still be hot enough to burn severely.
- 4. KEEP** children away from the range when it is on. The cooktop and oven walls, racks and door can get hot enough to cause burns.
- 5. DO NOT** use the range to heat a room. Persons in the room could be burned or injured, or a fire could start.
- 6. KEEP** pan handles turned in, but not over another surface unit to avoid burns, injury and to help prevent the utensil from being pushed off the surface units.
- 7. DO NOT** use water on grease fires. The fire will spread. Cover fire with large lid or smother with baking soda or salt.
- 8. DO NOT** wear loose or hanging garments when using the range. They could ignite if they touch a hot surface unit or heating element and you could be burned.
- 9. DO NOT** heat unopened containers. They could explode. The hot contents could burn and container particles could cause injury.
- 10. MAKE SURE** to open the oven door all the way when adding or removing food to prevent burns.

• FOR YOUR SAFETY •

**DO NOT STORE OR USE GASOLINE OR OTHER FLAMMABLE VAPORS AND LIQUIDS IN THE VICINITY OF THIS OR ANY OTHER APPLIANCE. THEY COULD IGNITE CAUSING EXPLOSION AND/OR FIRE.**

**– SAVE THESE INSTRUCTIONS –**

## Copy your Model and Serial Numbers here

If you need service, or call with a question, have this information ready:

- 1. Complete** Model and Serial Numbers (from plate just behind the oven door).

- 2. Purchase date** from sales slip.

Copy this information in these spaces. Keep this book, your warranty and sales slip together in the Literature Pac.

There is no warranty registration to return. Proof-of-purchase is all that is required for in-warranty service.

\_\_\_\_\_

Model Number

\_\_\_\_\_

Serial Number

\_\_\_\_\_



Purchase Date


\_\_\_\_\_

Service Company/Phone Number


# Parts and features

Model RF3000XP





## Using the surface units



**Control knobs must be pushed in before turning** them to a setting. They can be set anywhere between HI and OFF.

### Surface Unit Indicators

The solid dot in the surface unit indicator shows which surface unit is turned on by that knob.

### Signal Light

One of the signal lights will glow when a surface unit is on.



**WARNING:** Be sure all lights are OFF when you are not cooking. Someone could be burned or a fire could start if a surface unit is accidentally left ON.

**Until you get used to the settings, use the following as a guide.** For best results, start cooking at the high settings; then turn the control knob down to continue cooking.

**Use HI** to start foods cooking; to bring liquids to a boil.

**Use MED-HI** to hold a rapid boil; to fry chicken or pancakes.

**Use MED** for gravy, puddings and icing; to cook large amounts of vegetables.

**Use MED-LO** to keep food cooking after starting it on a higher setting.

**Use LO** to keep food warm until ready to serve. Set the heat higher or lower within the LO band to keep food at the temperature you want.

**CAUTION:** The use of the HI setting for long periods of time can damage surface units and discolor chrome reflector bowls. Start cooking on HI and turn control down to continue cooking.

Use only flat-bottomed utensils for best cooking results and to prevent damage to the cooktop. Specialty items with rounded or ridged bottoms (woks, ridged bottom canners or tea kettles) are not recommended.



**WARNING: The surface unit should never turn red during use. If it turns red, the bottom of the pan is not flat enough or is too small for the size of the surface unit. Damage to the surface unit, cooktop, wiring and/or surrounding area could result. If the pan is too small for the surface unit, you could be burned by the heat from the exposed section of the surface unit.**

See the "Cooking Guide" for important utensil information.

## Optional Canning Kit (Part No. 242905)

The large diameter of most water-bath or pressure canners combined with high heat settings for long periods of time can shorten the life of regular surface units and cause damage to the cooktop.


If you plan to use the cooktop for canning, we recommend the installation of a Canning Kit. Order the kit from your Whirlpool Dealer or Tech-Care® Service Company.

See the "Cooking Guide" for important canning information.

---


## Using the Oven Controls

### Baking




Rack(s) should be placed so the top of the food will be centered in the oven. Always leave at least 1½ to 2 inches (4-5 cm) between the sides of the pan and the oven walls and other pans. For more information, see the "Cooking Guide."


1. Position the rack(s) properly **before** turning on the oven. To **change rack position**, lift rack at front and pull out.



**2.** Set Oven Selector to BAKE.




**3.** Set Oven Temperature Control to the baking temperature you want. The Oven Signal Light will come on. The oven is preheated when the Oven Signal Light first goes off.



**4.** Put food in the oven. **Note: Oven racks, walls and door will be hot.**

During baking, the elements will turn on and off to keep the oven temperature at the setting. The Oven Signal Light will turn on and off with the elements.

**The top element helps heat during baking, but does not turn red.**




**5.** When baking is done, turn both the Oven Temperature Control and the Oven Selector to OFF.

### Adjusting the Oven Temperature Control


Does your oven seem hotter or colder than your old oven? The temperature of your old oven may have shifted gradually without your noticing the change. Your new oven is properly adjusted to provide accurate temperatures. But when comparing to your old oven, the new design may give you different results.

If after using the oven for a period of time, you are not satisfied with the temperature settings, they can be adjusted by following these steps:


continued on next page




1. Pull the Oven Temperature Control straight off.



2. Loosen the locking screws inside the control knob. **Note the position of the notches.**



3. **To lower the temperature**, move a notch closer to LO. Each notch equals about 10°F (5°C).



4. **To raise the temperature**, move a notch closer to HI. Each notch equals about 10°F (5°C).


**Tighten the locking screw and replace the control knob.**

## Broiling


A broiler pan and grid (Part Numbers 310976 and 258171) may be ordered from your Whirlpool Dealer.




**WARNING:** Always use a pan designed for broiling. The grid holds the food above the drippings and helps prevent excessive smoke and/or fire.




1. Position the rack before turning the oven on. See broil chart in the "Cooking Guide" or a reliable cookbook for recommended rack positions.




2. Put the broiler pan and food on the rack.



3. Close the door to the Broil Stop position, (open about 4 inches, 10.2 cm). The door will stay open by itself.



4. Set the Oven Selector and the Oven Temperature Control to BROIL.



5. When broiling is done, turn **both** the Oven Selector and the Oven Temperature Control to OFF.

### Custom Broil

- If food is cooking too fast, turn the Oven Temperature Control **counterclockwise** until the Oven Signal Light goes off.
- If you want the food to broil slower from the start, set the Oven Temperature Control between 150° and 325°F (65.5 and 142°C). The lower the temperature, the slower the cooking.

**The Oven Selector must be on BROIL for all broiling temperatures.**

**CAUTION: The door must be partly open whenever the oven is set to BROIL. Leaving the door open allows the oven to maintain proper temperatures.**


## The Oven Vent

Hot air and moisture escape from the oven through a vent under the right rear surface unit. You can cook on the unit, or keep food warm on it while the oven is on.

**CAUTION: Plastic utensils left over the vent can melt.**



**WARNING: If you leave a utensil on the right rear surface unit, use pot holders when moving it. Pan handles can become hot enough to burn.**




**Do not block the vent.** Poor baking can result.

## Optional Rotisserie

If you would like a rotisserie for your lower oven, you can order a kit (Part No. RCK79-261881) from your Whirlpool Dealer. The kit includes easy installation instructions.

## Caring for your range


### Control Panel




**WARNING: To avoid burns and possible electric shock, first make sure all controls are OFF and the range is COOL.**

1. Pull knobs straight off.
2. Use warm soapy water and a soft cloth, or spray glass cleaner, to wipe the control panel. Rinse and wipe dry.
3. Wash control knobs in warm soapy water. Rinse well and dry.
4. Push control knobs straight back on. Make sure they point to OFF.


## Surface Units and Reflector Bowls




-  **WARNING:** To avoid burns and possible electric shock, be sure surface units are **OFF** and **COOL**.



- Lift the edge of the unit, opposite the receptacle, just enough to clear the reflector bowl.




- Pull the surface unit straight away from the receptacle.




- Lift out the reflector bowl. See Cleaning Chart on page 14 for cleaning instructions.


## Replacing




-  **WARNING:** To avoid burns and possible electric shock, be sure surface units are **OFF**.



- Line up opening in the reflector bowl with the surface unit receptacle.



3. Hold the surface unit as level as possible with the terminal just started into the receptacle.



4. Push the surface unit terminal into the receptacle. When the terminal is pushed into the receptacle as far as it will go, the surface unit will fit into the reflector bowl.

**CAUTION: Reflector bowls reflect heat back to the utensils on the surface units. They also help catch spills. When they are kept clean, they reflect heat better and look new longer.**

**If a reflector bowl gets discolored, some of the utensils may not be flat enough, or some may be too large for the surface unit. In either case, some of the heat that's meant to go into or around a utensil goes down and heats the reflector bowl. This extra heat can discolor it. See "Cooking Guide" for further information.**



**WARNING – DO NOT LINE THE REFLECTOR BOWLS WITH FOIL.**  
Shock or fire hazard could result.


## Lift-Up Cooktop

1. Lift front of cooktop at center and swing-up the support rod.
2. Carefully lower the cooktop onto the support rod.



**WARNING: Be sure the rod fits in the notch in the cooktop and is held securely. It could accidentally fall and injure you.**

3. Wipe with warm soapy water. Use soapy steel-wool pad on stubborn spots.



**CAUTION: Do not drop the cooktop. Damage can result to the porcelain and the cooktop frame.**

## The Oven Door


Removing the oven door will help make it easier to clean the oven.

- 
**WARNING: To avoid burns, be sure the oven is OFF and COOL.**

Open the door to the first stop position.

- Hold the door at both sides and lift it **at the same angle it is in.**
- To replace,** fit the bottom corners of the door over the ends of the hinges.


Push the door down evenly. The door will close only when it is on the hinges correctly.




## The Lower Panel

The lower panel can be removed to help make it easier to clean under the range.

**To remove the lower panel:**




- Pull out bottom of panel.




- Slightly swing out and lift panel to remove from top clips.

**To replace lower panel:**



- Place notches in top of panel over the top clips.



- Swing down and push bottom of panel to secure bottom clips.

## Cleaning Chart

PART	WHAT TO CLEAN	HOW TO CLEAN
<b>Exterior surfaces</b>	Soft cloth and warm soapy water. Nylon or plastic scouring pad for stubborn spots.	<ul style="list-style-type: none"> <li>Wipe off regularly when cooktop and lower oven are cool.</li> <li><b>Do not allow food containing acids (such as vinegar, tomato, lemon juice or milk) to remain on surface. Acids will remove the glossy finish.</b></li> <li><b>Do not use abrasive or harsh cleansers.</b></li> </ul>
<b>Surface units</b>	No cleaning required.	<ul style="list-style-type: none"> <li>Spatters or spills will burn off.</li> <li><b>Do not immerse in water.</b></li> </ul>
<b>Chrome reflector bowls</b>	Automatic dishwasher or warm, soapy water and plastic scrubbing pad.	<ul style="list-style-type: none"> <li>Wash with other cooking utensils.</li> <li>Clean frequently.</li> <li><b>Do not use abrasive or harsh cleansers.</b></li> </ul>
<b>Control knobs</b>	Warm, soapy water and soft cloth.	<ul style="list-style-type: none"> <li>Wash, rinse and dry well.</li> <li><b>Do not soak.</b></li> </ul>
<b>Control panel</b>	Warm, soapy water or spray glass cleaner.	<ul style="list-style-type: none"> <li>Wash, rinse and dry well.</li> <li>Follow directions provided with cleaner.</li> </ul>
<b>Oven rack</b>	Warm, soapy water or soapy steel wool pads.	<ul style="list-style-type: none"> <li>Wash, rinse and dry. Use soapy steel wool pads for stubborn areas.</li> </ul>
<b>Standard oven</b>	Warm, soapy water or soapy steel wool pad. Commercial oven cleaners.	<ul style="list-style-type: none"> <li>Remove door for easier access.</li> <li>Place newspaper on floor to protect floor surface.</li> <li>Follow directions provided with the oven cleaner.</li> <li>Rinse well with clear water.</li> <li>Use in well ventilated room.</li> <li><b>Do not allow commercial oven cleaner to contact the heating elements, oven seal, or exterior surfaces of the range. Damage will occur.</b></li> </ul>

## If you need service or assistance, we suggest you follow these four steps:

### 1. Before calling for assistance...

Performance problems often result from little things you can fix yourself without tools of any kind.

#### If nothing operates:

- Is the power supply cord plugged into a live circuit with the proper voltage? (See "Installation Instructions.")
- Have you checked the main fuse or circuit breaker box?

#### If the oven will not operate:

- Is the Oven Selector turned to a setting (BAKE or BROIL)?
- Is the Oven Temperature Control turned to a temperature setting?

#### If surface units will not operate:

- Have you checked the main fuse or circuit breaker box?

- Are surface units plugged in all the way?
- Do the control knobs turn?

**If surface unit control knob(s) will not turn:**

- Did you push in before trying to turn?

**If cooking results aren't what you expected:**

- Is the range level?
- Are you using pans recommended in the **Cooking Guide**?
- If baking, have you allowed 1½ to 2 inches (4-5 cm) on all sides of the pans for air circulation?
- Have you preheated the oven as the recipe calls for?
- Are the pans the size called for in the recipe?
- Are you following a tested recipe from a reliable source?
- Do the cooking utensils have smooth, flat bottoms and fit the surface unit being used?

See the **Cooking Guide** for more information on cooking problems and how to solve them.

## 2. If you need assistance\*...

Call Whirlpool **COOL-LINE**® service assistance telephone number. Dial free from:

Continental U.S. . . (800) 253-1301  
 Michigan . . . . . (800) 632-2243  
 Alaska & Hawaii . (800) 253-1121

and talk with one of our trained Consultants. The Consultants can instruct you in how to obtain satisfactory operation from your appliance or, if service is necessary, recommend a qualified service company in your area.

## 3. If you need service\*...



Whirlpool has a nationwide network of franchised TECH-CARE® Service Companies. TECH-CARE service technicians are trained to fulfill the product warranty and provide after-warranty

service, anywhere in the United States. To locate TECH-CARE service in your area, call our COOL-LINE service assistance telephone number (see Step 2) or look in your telephone directory Yellow Pages under:

APPLIANCES - HOUSEHOLD - MAJOR - SERVICE & REPAIR	OR	ELECTRICAL APPLIANCES - MAJOR - REPAIRING & PARTS
WHIRLPOOL APPLIANCES FRANCHISED TECH-CARE SERVICE		WHIRLPOOL APPLIANCES FRANCHISED TECH-CARE SERVICE
SERVICE COMPANIES		SERVICE COMPANIES
XYZ SERVICE CO 123 Maple . . . . . 999-9999		XYZ SERVICE CO 123 Maple . . . . . 999-9999
OR		
WASHING MACHINES, DRYERS & IRONERS - SERVICING		
WHIRLPOOL APPLIANCES FRANCHISED TECH-CARE SERVICE		
SERVICE COMPANIES		
XYZ SERVICE CO 123 Maple . . . . . 999-9999		

## 4. If you have a problem\*...

Call our COOL-LINE service assistance telephone number (see Step 2) and talk with one of our Consultants, or if you prefer, write to:

Mr. Robert F. Gunts, Vice President  
 Whirlpool Corporation  
 Administrative Center  
 2000 US-33 North  
 Benton Harbor, MI 49022

\*If you must call or write, please provide: model number, serial number, date of purchase, and a complete description of the problem. This information is needed in order to better respond to your request for assistance.



FSP is a registered trademark of Whirlpool Corporation for quality parts. Look for this symbol of quality whenever you need a replacement part for your Whirlpool appliance. FSP replacement parts

will fit right and work right, because they are made to the same exacting specifications used to build every new Whirlpool appliance.



Making your world a little easier.

Part No. 313291  
©1984 Whirlpool Corporation

Printed in U.S.A.

matic Washers, Clothes Dryers, Freezers, Refrigerator-Freezers, Ice Makers, Dishwashers, Built-In Ovens and Surface Units, Ranges, Micr

