




# Use And Care

## G U I D E



**SELF-CLEANING ELECTRIC RANGE**

**MODEL RF377PXY**

## A NOTE TO YOU

# A Note To You

### Thank you for buying a Whirlpool appliance.

You have purchased a quality, *world-class* home appliance. Years of engineering experience have gone into its manufacturing. To ensure that you will enjoy many years of trouble-free operation, we have developed this Use and Care Guide. It is full of valuable information on how to operate and maintain your appliance properly and safely. Please read it carefully. Also, please complete and mail the Ownership Registration Card provided with your appliance.

### Your safety is important to us.

This guide contains safety symbols and statements. Please pay special attention to these symbols and follow any instructions given. Here is a brief explanation of the use of each symbol.

#### **WARNING**

This symbol will help alert you to such dangers as personal injury, burns, fire and electrical shock.

#### **CAUTION**

This symbol will help you avoid actions which could cause product damage (scratches, dents, etc.) and damage to your personal property.

### Our Consumer Assistance Center number, 1-800-253-1301, is TOLL-FREE, 24 hours a day.

If you ever have a question concerning your appliance's operation, or if you need service, feel free to call our Consumer Assistance Center for help. When calling, you will need to know your appliance's complete model number and serial number. You can find this information on the model and serial number plate (see diagram on page 6). For your convenience, we have included a handy place below for you to record these numbers, the purchase date from the sales slip and your dealer's name and telephone number. Keep this book and the sales slip together in a safe place for future reference.

Model Number \_\_\_\_\_

Dealer Name \_\_\_\_\_

Serial Number \_\_\_\_\_

Dealer Phone \_\_\_\_\_

Purchase Date \_\_\_\_\_



## IMPORTANT SAFETY INSTRUCTIONS

# Important Safety Instructions

### **⚠️ WARNING**

To reduce the risk of fire, electrical shock, injury to persons, or damage when using the range, follow basic precautions, including the following:

#### **General**

- Read all instructions before using the range.
- Install or locate the range only in accordance with the provided Installation Instructions. It is recommended that the range be installed by a qualified installer. The range must be properly connected to electrical supply and grounded.



- **WARNING:** To reduce the risk of tipping of the appliance, the appliance must be secured by a properly installed anti-tip bracket. To check if the bracket is installed properly, see "The anti-tip bracket" on page 26.
- **CAUTION:** Do not store things children might want above the range. Children could be burned or injured while climbing on it.
- Do not leave children alone or unattended in area where the range is in use. They should never be allowed to sit or stand on any part of the range. They could be burned or injured.
- Do not operate the range if it is damaged or not working properly.
- Do not use the range for warming or heating the room. Persons could be burned or injured, or a fire could start.

- Use the range only for its intended use as described in this manual.



- Do not touch surface units, areas near units, heating elements or interior surfaces of oven. Surface units and heating elements may be hot even though they are dark in color. Areas near surface units and interior surfaces of an oven become hot enough to cause burns. During and after use, do not touch, or let clothing or other flammable materials contact surface units, areas near units, heating elements or interior surfaces of oven until they have had sufficient time to cool. Other surfaces of the range may become hot enough to cause burns; such as, the oven vent opening, the surface near the vent opening, the cooktop, the oven door and window.



- Do not wear loose or hanging garments when using the range. They could ignite if they touch a hot surface unit and you could be burned.

## IMPORTANT SAFETY INSTRUCTIONS

- Use only dry potholders. Moist or damp potholders on hot surfaces may result in burns from steam. Do not let potholder touch hot heating elements. Do not use a towel or bulky cloth for a potholder. It could catch on fire.
- Keep range vents unobstructed.
- Do not heat unopened containers. They could explode. The hot contents could cause burns and container particles could cause injury.
- Do not store flammable materials on or near the range. The fumes can create an explosion and/or fire hazard.

### **When using the cooktop**

- Select a pan with a flat bottom that is about the same size as the surface unit. If pan is smaller than the surface unit, some of the heating element will be exposed and may result in the igniting of clothing or potholders. Correct pan size also improves cooking efficiency.
- Check to be sure glass cooking utensils are safe for use on the range. Only certain types of glass, glass-ceramic, ceramic, earthenware or other glazed utensils are suitable for cooktops without breaking due to the sudden change in temperature.

- Never leave surface units unattended at high heat settings. A boilover could result and cause smoking and greasy spillovers that may ignite.



- Turn pan handles inward, but not over other surface units. This will help reduce the chance of burns, igniting of flammable materials, and spills due to bumping of the pan.

### **When using the oven**

- Always position oven rack(s) in desired location while oven is cool. If a rack must be removed while oven is hot, do not let potholder contact hot heating element in oven.
- Use care when opening oven door. Let hot air or steam escape before removing or replacing food.

## IMPORTANT SAFETY INSTRUCTIONS

### Grease

- Grease is flammable. Do not allow grease to collect around cooktop or in vents. Wipe spills immediately.



- Do not use water on grease fires. Never pick up a flaming pan. Smother flaming pan on range by covering with a well-fitted lid, cookie sheet or flat tray. Flaming grease outside of pan can be extinguished with baking soda or, if available, a multipurpose dry chemical or foam-type extinguisher.

### Care and cleaning

- Small amounts of formaldehyde and carbon monoxide are given off in the Self-Cleaning cycle from fiberglass insulation and food decomposition. Significant exposure to these substances can cause cancer or reproductive harm. Exposure can be minimized by venting with a hood or open window and wiping out excess food spills prior to self-cleaning.
- Do not use oven cleaners. No commercial oven cleaner or oven liner protective coating of any kind should be used in or around any part of the oven.
  - Before self-cleaning the oven, remove broiler pan, broiler grid, oven racks and other utensils. Do not use your oven to clean miscellaneous parts unless you are instructed to do so in this Use and Care Guide.
  - Do not clean door heat seal. It is essential for a good seal. Care should be taken not to rub, damage or move the seal. Clean only parts recommended in this Use and Care Guide.
  - Do not repair or replace any part of the range unless specifically recommended in this manual. All other servicing should be referred to a qualified technician.
  - Disconnect the electrical supply before servicing the range.




– SAVE THESE INSTRUCTIONS –


## PARTS AND FEATURES

# Parts And Features

This section contains captioned illustrations of your range. Use them to become familiar with the location and appearance of all parts and features.



## Control panel



# Using Your Range

<b>In This Section</b>		<b>Page</b>	<b>Page</b>
Using the surface units .....	7	Adjusting the oven temperature control.....	14
Positioning racks and pans .....	9	Broiling .....	14
For best air circulation .....	9	Broiling tips .....	15
Using aluminum foil for baking .....	10	Energy saving tips .....	16
The electronic oven controls .....	10	Using the electronic MEALTIMER™ control	16
Setting the clock .....	11	The oven vent .....	25
Using the electronic Minute Timer .....	12	The storage drawer .....	26
Using the Off/Cancel pad .....	12	The anti-tip bracket .....	26
Baking/roasting .....	13	Optional door panel pac .....	26

To obtain the best cooking results possible, you must operate your range properly. This section gives you important information for efficient and safe use of your range.

## Using the surface units


Control knobs must be pushed in before turning them to a setting. They can be set anywhere between HI and OFF.

### Surface unit markers

The solid dot in the surface unit marker shows which surface unit is turned on by that knob.

### Surface heating indicator light

The SURFACE HEATING Indicator Light on the control panel will glow when a surface unit is turned on.



**⚠ WARNING**

**Burn and Fire Hazard**

Be sure all control knobs are turned to OFF and all indicator lights are OFF when you are not cooking.

Someone could be burned or a fire could start if a surface unit is accidentally left ON.

## USING YOUR RANGE

Until you get used to the settings, use the following as a guide. For best results, start cooking at the high settings; then turn the control knob down to continue cooking.

SETTING	RECOMMENDED USE
HI	<ul style="list-style-type: none"> <li>To start foods cooking.</li> <li>To bring liquids to a boil.</li> </ul>
Medium-high	<ul style="list-style-type: none"> <li>To hold a rapid boil.</li> <li>To fry chicken or pancakes.</li> </ul>
Medium	<ul style="list-style-type: none"> <li>For gravy, pudding and icing.</li> <li>To cook large amounts of vegetables.</li> </ul>
Medium-low	<ul style="list-style-type: none"> <li>To keep food cooking after starting it on a higher setting.</li> </ul>
LO	<ul style="list-style-type: none"> <li>To keep food warm until ready to serve.</li> </ul>

### Solid element surface units

Before using a solid element surface unit for the first time, heat on HI setting for five minutes. The surface units will give off smoke as the protective coating, applied at the factory, finishes bonding to the surface.

Solid element surface units are made of heavy cast-iron to provide even cooking. Each surface unit has a built-in protective limiter as a safety feature. The limiter senses uneven cooking temperatures and automatically reduces the heat level. The limiter will sense uneven heat when a pan boils dry or when a pan is removed and the surface unit is left on. The heat level may also be reduced automatically if the bottom of the pan is not flat or if the pan is too large or too small for the element. This will result in longer cooking times.

Solid elements hold heat longer than conventional surface units. For best cooking results, use a high setting for only a short period of time. Then use a lower setting to complete the cooking. You may want to turn the solid element surface unit OFF a few minutes before you finish cooking.

#### NOTES:

- Solid elements stay hot for a long time. Do not use the HI setting for long periods of time or leave pans on hot elements when cooking is done. Burned food and damage to the cookware could result.
- Do not leave an empty utensil, or one which has boiled dry, on a hot surface unit. It can overheat and may damage the utensil or surface unit.
- Do not use canners, woks and specialty utensils with rounded, warped, ridged or dented bottoms. These could cause severe overheating which damages the utensil and/or surface unit.

### Cookware tips

There is no one brand of cooking utensil that is best for all people. Knowing something about pan materials and construction will help you select the correct cooking utensils for your needs.

- Use only flat-bottomed utensils that make good contact with the surface units. To check the flatness of a utensil:

- Turn it over and check the bottom of the pan by placing a ruler across it.
- Rotate the ruler in all directions. There should be no gaps between the pan and the ruler.

**NOTE:** Woks, canners and teakettles with flat bottoms suitable for use on your cooktop are now available in most houseware stores or departments.

- The pan should have straight sides and a tight-fitting lid.
- Choose medium to heavy gauge (thickness) pans that are fairly lightweight. Remember that a very heavy pan will be even heavier when filled with food.
- The pan material (metal or glass) affects how fast heat transfers from the surface unit through the pan material and how evenly heat spreads over the pan bottom.
- Handles should be made of a sturdy, heat-resistant material and be securely attached to the pan.

### Home canning information

The large diameter of most water-bath or pressure canners combined with high heat settings for long periods of time can shorten the life of surface units and cause damage to the cooktop.

#### To protect your range:

- Use flat-bottomed canners for best results. Some canners have ridged bottoms (porcelain enamel-ware) and are not recommended. They do not make good contact with the surface unit and cause severe overheating which damages the cooktop.
- For best results, use the largest surface unit. Also, use a canner which can be centered over the surface unit. Large diameter canners, if not properly centered, trap heat and can cause damage to the cooktop.
- Do not place canner on two surface units at the same time. Excessive heat build-up will damage the cooktop.
- Start with hot water. This reduces the time the control is set on high. Reduce heat setting to lowest position needed to keep water boiling.
- To prolong the life of the elements:
  - Prepare small batches at a time.
  - Do not use elements for canning all day.

## Positioning racks and pans

For baking/roasting with one rack, the rack should be placed so the top of the food will be centered in the oven. Always leave at least 1½ to 2 inches (4-5 cm) between the sides of the pan and the oven walls and other pans.

**For proper cooking, follow these guidelines for specific foods:**

- Angel and bundt cakes, yeast breads, frozen pies, large roasts and turkeys—place rack on lowest level.
- Casseroles, muffins, most quick breads and meats—place rack on second or third level from bottom.
- Cookies, biscuits, cakes and non-frozen pies—place rack on second or third level from bottom.

When baking on two racks, arrange racks on bottom and third level from bottom.

**NOTE:** For recommended rack placement when broiling, see a reliable cookbook.

### **⚠ WARNING**

#### **Personal Injury Hazard**

- Always position oven rack(s) in desired location before turning oven on. Be sure the rack(s) is level.
- If rack(s) must be moved while oven is hot, use potholders or oven mitts to protect hands.

Failure to follow the above precautions may result in personal injury.

## For best air circulation

The hot air must circulate around the pans in the oven for even heat to reach all parts of the oven.

- Place the pans so that one is not directly over the other.
- Allow 1½ to 2 inches (4-5 cm) of space around each pan and between pans and oven walls.
- Use only one cookie sheet in the oven at one time.

Use the following as a guide to determine where to place the pans.

#### **One pan**

Place in the center of the oven rack.


#### **Two pans**

Place in opposite corners of the oven rack.

#### **Three or four pans**

Place in opposite corners on each oven rack. Stagger pans so no pan is directly over another.

**NOTE:** "Oven peeking" may cause heat loss, longer cooking times and unsatisfactory baking or roasting results. Use a reliable kitchen timer to keep track of the cooking time.




## USING YOUR RANGE

### Using aluminum foil for baking

Use aluminum foil to catch spillovers from pies or casseroles.

- Place the foil on the oven rack below the rack with the food. The foil should have the edges turned up and be about 1 inch (3 cm) larger all around than the dish holding the food.
- Do not cover the entire rack with aluminum foil. It will reduce air circulation and cause poor cooking results.
- Do not line oven bottom or entire oven rack with foil or other liners. Poor baking will result.




### ⚠ WARNING

#### Electrical Shock and Fire Hazard

Do not allow foil to touch the heating elements because it will damage them and could result in shock or fire hazard.

### The electronic oven controls



There are three parts in the oven control section:

- The display
- The command pads
- The control knobs

Instructions for each oven control are covered on the following pages. Read them carefully.

When you first plug in the range, "88:88" will appear in the display. If, after you set the clock (page 11) "88:88" again appears on the display, your electricity was off for a while. Reset the clock.

### Display/clock

When you are not using the oven, this is an accurate clock. When using the oven or Minute Timer, the display will show the time settings and what command pads have been pressed.

When showing the time of day, the display will show the hour and minutes.

When using the Minute Timer, the display shows minutes and seconds in the following sequence:


- For settings from 1-59 minutes, the display will count down each second.
- For settings over 1 hour, the display will count down each minute.

When using Cook Time and/or Stop Time, the display shows hours and minutes.

## USING YOUR RANGE

### Control knobs

There are two control knobs: the Oven Selector and the Oven Temperature Control Knob. The Oven Selector tells the oven which mode you wish to cook in (Bake, Broil, Time Bake), while the Oven Temperature Control Knob lets you set a specific cooking temperature. When using the MEALTIMER™ control you will use these knobs along with command pads (see "Using the electronic MEALTIMER™ control" on page 16).



### Command pads

The command pads tell the oven what to do and in what order. A few examples:

- Clock/Set tells the oven you are going to set the clock.
- Off/Cancel tells the oven or Minute Timer to turn off.

Each command pad (except Off/Cancel and Start/Enter) has its own indicator. The indicator comes on when you touch the command pad.

---

## Setting the clock

1. Push the Clock/Set pad. The colon flashes and the previously set time of day will light up in the display.


CLOCK

SET



2. Use the Hour and Minute pads to set the time of day. Push the "up" (▲) or "down" (▼) pad(s) until the correct time shows in the display.

HOUR MINUTE



3. Push the Start/Enter pad.

**NOTE:** If you do not want the clock time displayed, push and hold the Clock/Set pad for 4 seconds. To display the clock time again, push the Clock/Set pad once.


START  
ENTER

## USING YOUR RANGE

### Using the electronic Minute Timer

The Minute Timer does not start or stop the oven. It works like a kitchen timer. It can be set in hours and minutes up to 11 hours, 59 minutes. The Minute Timer will display minutes and seconds for settings under one hour. You will hear four 1-second tones when the set time is up.

1. Push the Timer Set pad. The Timer Indicator Light will come on and the display will show "0:00" with the colon flashing.



2. Use the Hour and Minute pads to set the desired time. Push the "up" (▲) or "down" (▼) pad(s) until the correct time shows in the display.



3. Push the Start/Enter pad. The Minute Timer will begin counting down immediately after the timer is started.


When time is up, "End" will show in the display and you will hear four ½-second tones. You will also hear two 1-second tones every minute until you push one of the two Timer pads.

**NOTE:** To disable the reminder tones, push and hold the Timer Set pad for four seconds. To reactivate the tones, repeat this procedure.



#### To cancel the Minute Timer:

- Push the Timer Off pad. The time of day will show in the display.




### Using the Off/Cancel pad

The Off/Cancel pad will cancel any command pad except for the Clock/Set and Timer Set pads. When the Off/Cancel pad is pushed, the display will show the time of day or, if Minute Timer is also being used, the time remaining.




## Baking/roasting


1. Position the rack(s) properly before turning on the oven. **To change rack position, lift rack at front and pull out.** See "Positioning racks and pans" on page 9.
2. Set the Oven Selector to **BAKE**.
3. Set the Oven Temperature Control Knob to the baking/roasting temperature you want. The **OVEN HEATING** Indicator Light will come on. The oven is preheated when the **OVEN HEATING** Indicator Light first goes off.  
**NOTE:** Do not preheat oven when roasting or cooking items such as casseroles.



4. Put food in the oven.  
During baking/roasting, the elements will turn on and off to maintain the temperature setting. The **OVEN HEATING** Indicator Light will turn on and off with the elements.  
**NOTE:** The top element helps heat during baking/roasting, but does not turn red.



5. When baking/roasting is done, turn both the Oven Selector and the Oven Temperature Control Knob to **OFF**. The **OVEN HEATING** Indicator Light will go off.




## USING YOUR RANGE

### Adjusting the oven temperature control


Does your oven seem hotter or colder than your old oven? The temperature of your old oven may have shifted gradually without you noticing the change. Your new oven is properly adjusted to provide accurate temperatures. But, when compared to your old oven, the new design may give you different results.

If, after using the oven for a period of time, you are not satisfied with the temperature settings, they can be adjusted by following these steps:

1. Turn the Oven Temperature Control Knob to the off position. Pull knob straight off and flip it over.



2. Loosen the locking screws inside the control knob. **Note the position of the notches.**
3. **To lower the temperature**, hold knob handle firmly and move the tooth a notch counter-clockwise to LO. Each notch equals about 5°F (2.5°C).
4. **To raise the temperature**, hold knob handle firmly and move the tooth a notch clockwise. Each notch equals about 5°F (2.5°C).




Tighten the locking screws and replace the control knob.

### Broiling

1. Position the rack before turning the oven on. See "Positioning racks and pans" on page 9.
2. Put the broiler pan and food on the rack.
3. Close the door to the Broil Stop position (open about 4 inches [10.2 cm]). The door will stay open by itself.
4. Set the Oven Selector and Oven Temperature Control Knob to BROIL. The OVEN HEATING Indicator Light will come on.

**NOTE:** Do not preheat oven when broiling.

5. When broiling is done, turn **both** the Oven Selector and Oven Temperature Control Knob to OFF. The OVEN HEATING Indicator Light will go off.



### Custom broil

- If food is cooking too fast, turn the Oven Temperature Control Knob **counterclockwise** until the OVEN HEATING Indicator Light goes off.
- If you want the food to broil slower from the start, set the Oven Temperature Control Knob between 170°F and 325°F (77°C and 163°C). These temperature settings allow the broil heating element to cycle and to slow cooking. The lower the temperature, the slower the cooking.
- Fish and chicken are some foods that may cook better if you use lower broiling temperatures.

**The Oven Selector must be on BROIL for all broiling temperatures.**

**NOTE:** The oven door must be partly open whenever the oven is being used to broil. Leaving the door open allows the oven to maintain proper temperatures.

---

### Broiling tips

- Use the broiler pan and grid for broiling. They are designed to drain excess liquid and fat away from the cooking surface to help prevent spatter, smoke or fire.
- Refer to a broiling chart in a reliable cookbook for correct broiling times.
- After broiling, remove the broiler pan from the oven when you remove the food. Drippings will bake on the pan if it is left in the heated oven.

#### **⚠ WARNING**

##### **Fire Hazard**

- Place meat the correct distance from the element. Meat placed too close to the element may spatter, smoke, burn or catch fire during broiling.
- To ensure adequate grease drainage, do not use cookie sheets or similar pans for broiling. Also, covering the broiler grid with foil is not recommended. Poor drainage of grease may result in fire. If foil is used, cut slits in foil to correspond with all openings in broiler grid. Grease can then drain away and cool in pan.

## USING YOUR RANGE

### Energy saving tips

Although the energy used for cooking is usually a very small percentage of the total energy used in the home, cooking energy can be used efficiently. Here are some tips to help you conserve energy when using your cooking product.

- Use pans with flat bottoms, straight sides and tight-fitting lids.
- Match the pan to the surface unit size.
- Cook with a minimum of liquid or fat to help shorten cooking time.
- Preheat pans only when recommended and for the shortest time possible.
- Start food on higher heat settings, then set surface unit control on low or off to finish cooking. Use retained heat for cooking when possible.
- Use the more efficient surface units instead of the oven when possible.

- Turn on the surface unit only after placing filled pan on the unit.
- "Oven peeking" may cause heat loss, longer cooking times and unsatisfactory baking results. Rely on your timer.
- Bake cakes, pies or cookies when oven is warm. Best time is after a meal has been cooked in it.
- Preheat the oven no longer than necessary.
- Plan your meals for the most efficient use of the range. When using the oven to cook one food, try to cook the rest of the meal in it also.
- Do not preheat when broiling, roasting or cooking items such as casseroles.

### Using the electronic MEALTIMER™ control

The electronic MEALTIMER™ control will turn the oven on and off at times you set ... even when you are not around.


Automatic baking/roasting is ideal for foods which do not require a preheated oven, such as meats and casseroles. Do not use the automatic cycle for cakes, cookies, etc. ... undercooking will result.

This section instructs you in two methods of starting baking/roasting now and stopping automatically later, and three methods of starting and stopping automatically. Read this section carefully to determine which method(s) is best for you.

#### To start baking/roasting now and stop automatically

##### Method 1—Using Cook Time:

1. Position the oven rack(s) properly and put food in the oven.
2. Make sure the clock is set to the correct time of day. (See "Setting the clock" on page 11.)
3. Set the Oven Selector to TIME BAKE.
4. Set the Oven Temperature Control Knob to the desired temperature.




## USING YOUR RANGE

5. Push the Cook Time pad. "0:00" with the colon flashing and the Cook Time Indicator Light will show in the display.



6. Use the Hour and Minute pads to set the desired cooking time. Push the "up" (▲) or "down" (▼) pad(s) until the correct time shows in the display.



This example shows a desired baking/roasting time of 30 minutes.



COOK TIME

7. Push the Start/Enter pad. The Oven Heating Indicator Light will come on.

**NOTE:** You can change the Cook Time after pushing the Start/Enter pad without pushing the Start/Enter pad again.

8. The display will count down the baking/roasting time in minutes.
9. When the baking/roasting time is completed, the oven will turn off automatically, beep four times, and "End" will show in the display. You will also hear two tones once every minute until you push the Off/Cancel pad.

**NOTE:** To disable the reminder tones, push and hold the Timer Set pad for 4 seconds. To reactivate the tones, repeat this procedure.




COOK TIME

BEEP BEEP BEEP BEEP

10. Push the Off/Cancel pad to return the display to the time of day.




11. Turn both the Oven Selector and the Oven Temperature Control Knob to OFF.



## USING YOUR RANGE

### Method 2—Using Stop Time:


1. Position the oven rack(s) properly and put food in the oven.
2. **Make sure the clock is set to the correct time of day.** (See "Setting the clock" on page 11.)
3. Set the Oven Selector to TIME BAKE.
4. Set the Oven Temperature Control Knob to the desired temperature.



5. Push the Stop Time pad. The time of day with the colon flashing and the Stop Time Indicator Light will show in the display.



6. Use the Hour and Minute pads to set the desired stop time. Push the "up" (▲) or "down" (▼) pad(s) until the correct time shows in the display.




This example shows a desired stop time of 2 o'clock. The cook time will be the difference between the stop time and the current time of day.

7. Push the Start/Enter pad. The Oven Heating Indicator Light will come on.  
**NOTE:** You can change the Stop Time after pushing the Start/Enter pad without pushing the Start/Enter pad again.



8. The display will count down the baking/roasting time in minutes.
9. When the baking/roasting time is completed, the oven will turn off automatically, beep four times, and "End" will show in the display. You will also hear two tones once every minute until you push the Off/Cancel pad.

**NOTE:** To disable the reminder tones, push and hold the Timer Set pad for 4 seconds. To reactivate the tones, repeat this procedure.




## USING YOUR RANGE

10. Push the Off/Cancel pad to return the display to the time of day.

OFF  
CANCEL


11. Turn both the Oven Selector and the Oven Temperature Control Knob to OFF.



### To delay start and stop automatically

#### Method 1—Using Cook Time and Start Time:

1. Position the oven rack(s) properly and put food in the oven.
2. **Make sure the clock is set to the correct time of day.** (See "Setting the clock" on page 11.)
3. Set the Oven Selector to TIME BAKE.
4. Set the Oven Temperature Control Knob to the desired temperature.



5. Push the Cook Time pad. "0:00" with the colon flashing and the Cook Time Indicator Light will show in the display.

COOK  
TIME

6. Use the Hour and Minute pads to set the desired cooking time. Push the "up" (▲) or "down" (▼) pad(s) until the correct time shows in the display.

HOUR MINUTE



This example shows a desired baking/roasting time of 30 minutes.



COOK  
TIME

## USING YOUR RANGE

- Push the Delay Start Time pad. The time of day with the colon flashing will show in the display, the Start Time Indicator Light will light up, and the Cook Time Indicator Light will flash.



- Use the Hour and Minute pads to set the desired start time. Push the "up" (▲) or "down" (▼) pad(s) until the correct start time shows in the display.



This example shows a desired start time of 2 o'clock. The oven will automatically shut off at 2:30 (the set start time plus the set cook time).



- Push the Start/Enter pad. The Delay Indicator Light will light up in the display to indicate that the oven is programmed to start at a later time. The Cook Time and Start Time Indicator Lights will flash.



DELAY



- When the start time is reached, the Delay Indicator Light will go off, a single tone will sound and the display will count down the baking/roasting time in minutes.



- When the baking/roasting time is completed, the oven will turn off automatically, beep four times, and "End" will show in the display. You will also hear two tones once every minute until you push the Off/Cancel pad.




**NOTE:** To disable the reminder tones, push and hold the Timer Set pad for 4 seconds. To reactivate the tones, repeat this procedure.

**BEEP BEEP BEEP BEEP**

## USING YOUR RANGE

- Turn both the Oven Selector and the Oven Temperature Control Knob to OFF.




To cancel the MEALTIMER™ control setting:

- Push the Off/Cancel pad to return the display to the time of day.




### Method 2—Using Start Time and Stop Time:

- Position the oven rack(s) properly and put food in the oven.
- Make sure the clock is set to the correct time of day. (See "Setting the clock" on page 11.)
- Set the Oven Selector to TIME BAKE.
- Set the Oven Temperature Control Knob to the desired temperature.



- Push the Delay Start Time pad. The time of day with the colon flashing will show in the display and the Start Time Indicator will light up.
- Use the Hour and Minute pads to set the desired start time. Push the "up" (▲) or "down" (▼) pad(s) until the correct time shows in the display.




This example shows a desired start time of 2 o'clock.




## USING YOUR RANGE

7. Push the Stop Time pad. The time of day with the colon flashing will show in the display, the Stop Time Indicator Light will light up, and the Start Time Indicator Light will flash.



8. Use the Hour and Minute pads to set the desired stop time. Push the "up" (▲) or "down" (▼) pad(s) until the correct time shows in the display.



This example shows a desired stop time of 2:30. This provides a cook time of 30 minutes (the difference between the start and stop times).

**NOTE:** If you do not set a stop time within 5 minutes, the display will return to the time of day.

9. Push the Start/Enter pad. The Delay Indicator Light will light up in the display to indicate that the oven is programmed to start at a later time. The Start Time and Stop Time Indicator Lights will flash.

**NOTE:** You can change a time setting after pushing the Start/Enter pad without pushing the Start/Enter pad again.



10. When the start time is reached, the Delay Indicator Light will go off, a single tone will sound and the display will count down the baking/roasting time in minutes. The example at right shows a baking/roasting time of 30 minutes (the difference between the stop and start times).



11. When the baking/roasting time is completed, the oven will turn off automatically, beep four times, and "End" will show in the display. You will also hear two tones once every minute until you push the Off/Cancel pad.




**NOTE:** To disable the reminder tones, push and hold the Timer Set pad for 4 seconds. To reactivate the tones, repeat this procedure.

**BEEP BEEP BEEP BEEP**

## USING YOUR RANGE

- Turn both the Oven Selector and the Oven Temperature Control Knob to OFF.




To cancel the MEALTIMER™ control setting:

- Push the Off/Cancel pad to return the display to the time of day.



### Method 3—Using Cook Time and Stop Time:


- Position the oven rack(s) properly and put food in the oven.
- Make sure the clock is set to the correct time of day. (See "Setting the clock" on page 11.)
- Set the Oven Selector to TIME BAKE.
- Set the Oven Temperature Control Knob to the desired temperature.



- Push the Cook Time pad. "0:00" with the colon flashing and the Cook Time Indicator Light will show in the display.



- Use the Hour and Minute pads to set the desired cooking time. Push the "up" (▲) or "down" (▼) pad(s) until the correct time shows in the display.




This example shows a desired baking/roasting time of 30 minutes.



## USING YOUR RANGE


- Push the Stop Time pad. The time of day with the colon flashing will show in the display, the Stop Time Indicator Light will light up, and the Cook Time Indicator Light will flash.



- Use the Hour and Minute pads to set the desired stop time. Push the "up" (▲) or "down" (▼) pad(s) until the correct time shows in the display.


This example shows a desired stop time of 2:30. The oven will automatically start cooking at 2:00 (the set stop time minus the set cook time).

**NOTE:** If you do not set a stop time within 5 minutes, the display will return to the time of day.



- Push the Start/Enter pad. The Delay Indicator Light will light up in the display to indicate that the oven is programmed to start at a later time. The Cook Time and Stop Time Indicator Lights will flash.

**NOTE:** You can change a time setting after pushing the Start/Enter pad without pushing the Start/Enter pad again.



- When the start time is reached, the Delay Indicator Light will go off, a single tone will sound and the display will count down the baking/roasting time in minutes.



## USING YOUR RANGE


11. When the baking/roasting time is completed, the oven will turn off automatically, beep four times, and "End" will show in the display. You will also hear two tones once every minute until you push the Off/Cancel pad.

**NOTE:** To disable the reminder tones, push and hold the Timer Set pad for 4 seconds. To reactivate the tones, repeat this procedure.



COOK TIME  
BEEP BEEP BEEP BEEP

12. Turn both the Oven Selector and the Oven Temperature Control Knob to OFF.



**To cancel the MEALTIMER™ control setting:**

- Push the Off/Cancel pad to return the display to the time of day.



### ⚠ WARNING


**To avoid sickness and food waste when using the MEALTIMER™ control:**

- Do not let most UNFROZEN food stand for more than two hours before cooking starts.
- Do not allow food to remain in oven for more than two hours after the end of cooking cycle.

**NOTE:** Do not use foods that will spoil while waiting for cooking to start. Such foods are: dishes with milk or eggs, cream soups and cooked meats or fish. Also, foods containing baking powder or yeast will not rise properly when cooked using delay start.

## The oven vent

Hot air and moisture escape from the oven through a vent on the backguard below the control panel. The vent is needed for air circulation. **Do not block the vent.** Poor baking/roasting can result.




### The storage drawer

The storage drawer is for storing pots and pans. The drawer can be removed to make it easier to clean under the range. **Use care when handling the drawer.**


#### Removing the storage drawer:

1. Empty drawer of any pots and pans before removing drawer. Pull drawer straight out to the first stop. Lift front and pull out to the second stop.
2. Lift back slightly and slide drawer all the way out.



#### Replacing the storage drawer:

1. Fit ends of drawer slide rails into the drawer guides on both sides of opening.
2. Lift drawer front and push in until metal stops on drawer slide rails clear white stops on drawer guides. Lift drawer front again to clear second stop and slide drawer closed.




Drawer slide rail

### The anti-tip bracket

The range will not tip during normal use. However, tipping can occur if excessive force or weight is applied to the open door without the anti-tip bracket properly secured.

#### To verify the anti-tip bracket is engaged:

- Look to see if the anti-tip bracket is attached with screws to the wall behind the control panel.
- Make sure the cable tether on the back of the range is secured by the two hooks on the bracket.
- See Installation Instructions for further details.



### Optional door panel pac

If you would like to change the color of your oven door glass to white or almond, you can order one of these kits:

- White (Kit No. 814069)
- Almond (Kit No. 814070)

from your Whirlpool Dealer. The kits include easy installation instructions.

# Using The Self-Cleaning Cycle

In This Section		Page	Page
How the cycle works .....	27	Setting the controls .....	28
Before you start .....	27	Special tips .....	30


The Self-Cleaning cycle saves you from the toil and mess that often come with hand-cleaning the oven interior. Like the other functions of your range, the Self-Cleaning cycle is operated with the easy-to-use electronic controls. Please review the instructions in this section to keep your oven spotless.

## How the cycle works

The Self-Cleaning cycle uses very high heat to burn away soil and grease. During the cycle, the oven gets much hotter than it does for normal baking or broiling—approximately 875°F (468°C). This high heat breaks up the soil or grease and burns it away.

Your oven is preset for a 3-hour Self-Cleaning cycle. However, the cycle time can be adjusted to the amount of soil in your oven. The cycle can be set anywhere between 2 and 4 hours. (See "Setting the controls" on page 28.)

The graph at the right is representative of a normal, 3-hour Self-Cleaning cycle. Note that the heating stops when the 3-hour setting is up, but it takes longer for the oven to cool enough to unlock.




## Before you start

Before you start the Self-Cleaning cycle, make sure you:

1. Hand-clean the indicated areas. They do not get hot enough during the cleaning cycle for soil to burn away. Use hot water and detergent or a soapy steel-wool pad for cleaning.

**NOTE:** DO NOT clean, move or bend the fiberglass seal. Poor cleaning, baking and roasting may result.



## USING THE SELF-CLEANING CYCLE

2. Remove the broiler pan grid and any pots and pans being stored in the oven.

**NOTE:** The broiler pan (without grid) can be cleaned in the oven if most of the soil is removed first by hand-cleaning or a dishwasher. If most of the soil is not removed, excessive smoking will occur. The chrome broiler pan grid will discolor if cleaned in the Self-Cleaning cycle.

3. Wipe out any loose soil or grease. This will help reduce smoke during the cleaning cycle.
4. Remove the oven racks from the oven if you want them to remain shiny. If the oven racks are cleaned in the Self-Cleaning cycle, place them on the 2nd and 4th rack guides. (Guides are counted from bottom to top.)

**NOTE:** If oven racks are cleaned in the Self-Cleaning cycle, they will become harder to slide.

Heat and odors are normal during the Self-Cleaning cycle. If needed, remove them by opening a window or by turning on a vent hood or other kitchen vent during the cycle.

### ⚠ WARNING

#### Personal Injury and Product Damage Hazard

- Do not touch the oven during the Self-Cleaning cycle. It could burn you.
- Do not use commercial oven cleaners in your oven. Cleaners may produce hazardous fumes or damage the porcelain finish.
- Do not leave foil in the oven during the Self-Cleaning cycle. Foil can burn or melt and damage the oven surface.


**NOTE:** Do not force the Lock Lever. You could bend or break it. The lever is designed to stay locked until the oven is cool enough to safely open. Wait until it moves freely.

Do not block the vent during the Self-Cleaning cycle. Air must move freely for best cleaning results.

Do not leave plastic utensils near the vent. They may melt.


## Setting the controls

1. Make sure the clock is set to the correct time of day. (See "Setting the clock" on page 11.)
2. Move the Lock Lever all the way to the right—the Clean position.



3. To start cleaning immediately:

Set both the Oven Selector and Oven Temperature Control Knob to CLEAN. A 3-hour Self-Cleaning cycle will be set automatically. "C3:00" with the colon flashing will show in the display and the Clean Time Indicator Light will come on.



CLEAN  
TIME

## USING THE SELF-CLEANING CYCLE

If a cleaning cycle other than 3 hours is desired, use the Hour and Minute pads to set the desired cleaning time. Push the "up" (▲) or "down" (▼) pad(s) until a time between 2-4 hours shows in the display.

- Use 2 hours for light soil.
- Use 3-4 hours for moderate to heavy soil.

Push the Start/Enter pad. The Clean Time Indicator Light will stay on to show that the oven is programmed for the Self-Cleaning cycle.

Skip to Step 6 if you want the Self-Cleaning cycle to start now.

#### 4. To delay the start using Stop Time:

Set both the Oven Selector and Oven Temperature Control Knob to CLEAN. Push the Stop Time pad. The Clean Time Indicator Light will flash and the Stop Time Indicator Light will light up. Use the Hour and Minute pads to set the desired stop time. Push the "up" (▲) or "down" (▼) pad(s) until the correct time shows in the display. The oven will automatically compute the delay start time by subtracting the set cleaning time from the set stop time.

Push the Start/Enter pad. The display will go back to showing the current time of day. The Delay Indicator Light will light up and the Clean Time and Stop Time Indicator Lights will flash to indicate that the oven is programmed to start the Self-Cleaning cycle at a later time.



When the start time is reached, the Delay Indicator Light will go off, the Clean Time Indicator Light will light up (stop flashing) and the oven will start to clean.

#### 5. To delay the start using Start Time:

Set both the Oven Selector and Oven Temperature Control Knob to CLEAN. Push the Delay Start Time pad. The Clean Time Indicator Light will flash and the Start Time Indicator Light will light up. Use the Hour and Minute pads to set the desired start time. Push the "up" (▲) or "down" (▼) pad(s) until the correct time shows in the display.

Push the Start/Enter pad. The display will go back to showing the current time of day. The Delay Indicator Light will light up and the Clean Time and Start Time Indicator Lights will flash to indicate that the oven is programmed to start the Self-Cleaning cycle at a later time.

When the start time is reached, the Delay Indicator Light will go off, the Clean Time Indicator Light will light up (stop flashing) and the oven will start to clean.



## USING THE SELF-CLEANING CYCLE

6. After the Self-Cleaning cycle is started, the oven door will lock when the oven temperature exceeds normal baking/roasting temperatures. The Lock Lever must not be moved and the door cannot be opened.




CLEAN  
TIME

7. After the Self-Cleaning cycle is completed, "End" will show in the display and four tones will sound.




CLEAN  
TIME

8. Turn both the Oven Selector and Oven Temperature Control Knob to OFF.



9. When the oven reaches normal baking/roasting temperatures, move the Lock Lever back to the left. **DO NOT FORCE IT.** Wait until it moves easily. Wait at least one hour after the Self-Cleaning cycle has ended before trying to move the Lock Lever.



### To stop the Self-Cleaning cycle at any time:

1. Push the Off/Cancel pad.
2. When the oven reaches normal baking/roasting temperatures, move the Lock Lever back to the left. **DO NOT FORCE IT.** Wait until it moves easily.
3. Turn both the Oven Selector and Oven Temperature Control Knob to OFF.



### Special tips

- Keep the kitchen well ventilated during the Self-Cleaning cycle to help get rid of heat, odors and smoke.
- After the oven is cool, wipe up any residue or ash with a damp cloth.
- Clean the oven before it gets heavily soiled. Cleaning a very soiled oven takes longer and results in more smoke than usual.
- If the Self-Cleaning cycle does not get the oven as clean as you expected, the cycle may not have been set long enough or you may not have prepared the oven properly. Set the Self-Cleaning cycle longer the next time and hand-clean areas noted on page 27.

# Caring For Your Range

In This Section	
	Page
Cleaning the solid element surface units .....	31
Cleaning other range parts .....	33
The oven light .....	34

Your range is designed for ease of care. Most cleaning can be done with items found around your home. Cleaning your range whenever spills or soiling occurs will help to keep it looking and operating like new.

**⚠ WARNING**


**Burn and Electrical Shock Hazard**  
Make sure all controls are OFF and the range is cool before cleaning.  
Failure to do so can result in burns or electrical shock.

## Cleaning the solid element surface units

**⚠ WARNING**


**Burn and Electrical Shock Hazard**  
Solid element surface units do not glow red when hot. Make sure all controls are OFF and the range is COOL before cleaning. Failure to do so can result in burns or electrical shock.

1. Make sure all surface units are off.



2. For best results, wipe off surface units with a damp, soft cloth and soapy water after each use. Remove burned-on food with a soap-filled scrubbing pad. Rinse well. The red spot in the center of the surface unit will gradually wash off. This is normal and will not affect the operation of the surface unit.

**NOTE:** Make sure plastic scrubbing pad does not contain metal or abrasive particles. Do not use abrasive cleaners.



## CARING FOR YOUR RANGE

**3. IMPORTANT:** Dry the element completely after cleaning. Turn on the element for a few minutes to dry thoroughly. After the element has cooled, use a paper towel to apply a thin coat of salt-free oil to the surface units to season and restore the finish. Wipe excess oil off stainless steel trim rings. Then heat 3-5 minutes. Some smoking may occur; this is normal. If surface units have dark spots caused by grease and food, the oil treatment will improve their appearance, but not eliminate the spots.


**Optional:** Electro<sup>®</sup> dressing can be applied to the surface units to improve their appearance.

To order information for Electro<sup>®</sup> Dressing (Part No. 814030) write to:

Whirlpool Corporation  
Attention: Customer Service Department  
1900 Whirlpool Drive  
LaPorte, IN 46350

**OR**

Call 1-800-253-1301 to order. You must have a major credit card to order by phone.



## Cleaning other range parts

Use the following table to help you clean all other parts of your range.

PART	WHAT TO USE	HOW TO CLEAN
<b>Control knobs</b>	Sponge and warm, soapy water	<ul style="list-style-type: none"> <li>• Turn knobs to OFF and pull straight away from control panel.</li> <li>• Wash, rinse and dry thoroughly. Do not soak.</li> <li>• Replace knobs. Make sure all knobs point to OFF.</li> </ul> <p>DO NOT USE steel wool or abrasive cleaners. They may damage the finish of the knobs.</p>
<b>Control panel</b>	Sponge and warm, soapy water <b>OR</b> Paper towel and spray glass cleaner	<ul style="list-style-type: none"> <li>• Wash, rinse and dry thoroughly.</li> </ul> <p>DO NOT USE steel wool or abrasive cleaners. They may damage the finish. <b>NOTE:</b> Make sure you have not turned the oven on when cleaning panel. If you have, push the Off/Cancel pad.</p>
<b>Exterior surfaces (other than control panel)</b>	Sponge and warm, soapy water	<ul style="list-style-type: none"> <li>• Wash, rinse and dry thoroughly.</li> </ul> <p>USE nonabrasive, plastic scrubbing pad on heavily soiled areas.</p> <ul style="list-style-type: none"> <li>• Do not use abrasive or harsh cleansers.</li> </ul>
<b>Broiler pan and grid (clean after each use)</b>	Steel-wool pad and warm, soapy water	<ul style="list-style-type: none"> <li>• Wash, rinse and dry thoroughly.</li> </ul> <p>DO NOT CLEAN in Self-Cleaning cycle. (See note on page 28.)</p>
<b>Oven racks</b>	Steel-wool pad and warm, soapy water <b>OR</b> The Self-Cleaning cycle	<ul style="list-style-type: none"> <li>• Wash, rinse and dry thoroughly.</li> </ul> <p><b>OR</b></p> <ul style="list-style-type: none"> <li>• Leave in oven during Self-Cleaning cycle.</li> </ul> <p><b>NOTE:</b> Racks will permanently discolor and become harder to slide. Apply a small amount of vegetable oil to the side rungs to aid sliding.</p>
<b>Oven door glass</b>	Paper towel and spray glass cleaner <b>OR</b> Warm, soapy water and a nonabrasive, plastic scrubbing pad	<ul style="list-style-type: none"> <li>• Make sure oven is cool.</li> <li>• Follow directions provided with the cleaner.</li> <li>• Wash, rinse and dry thoroughly.</li> </ul>
<b>Oven cavity</b>	Self-Cleaning cycle	<ul style="list-style-type: none"> <li>• See "Using The Self-Cleaning Cycle" on pages 27-30.</li> </ul>

## The oven light

The oven light will come on when you open the oven door. To turn the light on when the oven door is closed, use the Oven Light Switch on the control panel.

### **⚠ WARNING**

#### **Electrical Shock and Personal Injury Hazard**



- Make sure oven and light bulb are cool and power to the range has been turned off before replacing the light bulb. Failure to do so could result in electrical shock or burns.
- The bulb cover must be in place when using the oven. The cover protects the bulb from breaking, and from high oven temperatures. Because bulb cover is made of glass, be careful not to drop it. Broken glass could cause injury.

#### **To replace the oven light:**

1. Unplug appliance or disconnect at the main power supply.
2. Remove the glass bulb cover in the back of the oven by screwing it out counterclockwise.
3. Remove the light bulb from its socket. Replace the bulb with a 40-watt appliance bulb.

4. Replace the bulb cover by screwing it in clockwise. Plug in appliance or reconnect at the main power supply.

**NOTE:** The oven light will not work during the Self-Cleaning cycle.



**IF YOU NEED ASSISTANCE OR SERVICE**

# If You Need Assistance Or Service

This section is designed to help you save the cost of a service call. First we outline possible problems, their causes and their solutions. However, you may still need assistance or service. When calling our Consumer Assistance Center for help or calling for service, you will need to provide a complete description of the problem, your appliance's complete model and serial numbers and the purchase date. (See page 2.) This information is needed to respond to your request properly.

## 1. Before calling for assistance ...

Performance problems often result from little things you can find and fix without tools of any kind. Please check the chart below for problems you can fix. It could save you the cost of a service call.

<b>PROBLEM</b>	<b>POSSIBLE CAUSE</b>	<b>SOLUTION</b>
<b>Nothing will operate</b>	The power cord is not plugged into a live circuit with proper voltage. A household fuse has blown or a circuit breaker has tripped.	Plug the power cord into a live circuit with proper voltage. (See Installation Instructions.) Replace household fuse or reset circuit breaker.
<b>The oven will not operate</b>	The Oven Selector is not turned to BAKE or BROIL. The Oven Temperature Control Knob is not turned to a temperature setting. A delayed start time has been programmed.	Turn the Oven Selector to the desired setting. Turn the Oven Temperature Control Knob to a temperature setting.  Wait for the start time to be reached.
<b>The surface units will not operate</b>	A household fuse has blown or a circuit breaker has tripped. The control knobs are not being set correctly.	Replace household fuse or reset circuit breaker. Push control knobs in before turning to a setting.
<b>Control knob(s) will not turn</b>	You are not pushing in before turning.	Push control knob(s) in before turning to a setting.
<b>Self-Cleaning cycle will not operate</b>	The Oven Selector and Oven Temperature Control Knob are not set to CLEAN. The range clock does not show the correct time of day. The Lock Lever is not in the CLEAN position—all the way to the right. A delayed start time has been programmed.	Set both the Oven Selector and Oven Temperature Control Knob to CLEAN.  Reset clock to show the correct time of day. (See page 11.) Move Lock Lever all the way to the right.  Wait for the start time to be reached.

continued on next page

## IF YOU NEED ASSISTANCE OR SERVICE

PROBLEM	POSSIBLE CAUSE	SOLUTION
<p><b>Cooking results are not what you expected</b></p>	<p>The range is not level.</p> <p>The oven temperature is too low or too high.</p> <p>The oven was not preheated before baking.</p> <p>The recipe has never been tested or is not from a reliable source.</p> <p>The pan used is not the type or size recommended in the recipe.</p> <p>There is not proper air circulation around pan when baking.</p> <p>Cooking utensil does not fit the surface unit being used.</p>	<p>Level range. (See Installation Instructions.)</p> <p>See page 14 for instructions on how to adjust the Oven Temperature Control. Preheat oven when called for in recipe.</p> <p>Use only tested recipes from a reliable source.</p> <p>Refer to a reliable cookbook for recommended pan type and size.</p> <p>Allow 1½ to 2 inches (4-5 cm) of air space on all sides of pan.</p> <p>Pan should be the same size or slightly larger than surface unit being used.</p>
<p><b>The display is flashing "88:88"</b></p>	<p>There has been a power failure.</p>	<p>Reset the clock. (See page 11.)</p>
<p><b>"F2" shows in the display</b></p>		<p>Call for service. (See Step 3 on page 37.)</p>

## IF YOU NEED ASSISTANCE OR SERVICE

### 2. If you need assistance ...

Call Whirlpool Consumer Assistance Center telephone number. Dial free from anywhere in the U.S.:

1-800-253-1301

and talk with one of our trained consultants. The consultant can instruct you in how to obtain satisfactory operation from your appliance or, if service is necessary, recommend a qualified service company in your area.

If you prefer, write to:

Mr. William Clark  
Consumer Assistance Representative  
Whirlpool Corporation  
2000 M-63  
Benton Harbor, MI 49022

Please include a daytime phone number in your correspondence.

### 3. If you need service ...



Whirlpool has a nationwide network of authorized Whirlpool<sup>SM</sup> service companies. Whirlpool service technicians are trained to

fulfill the product warranty and provide after-warranty service, anywhere in the United States. To locate the authorized Whirlpool service company in your area, call our Consumer Assistance Center telephone number (see Step 2) or look in your telephone directory Yellow Pages under:

• APPLIANCE-HOUSEHOLD-  
MAJOR, SERVICE & REPAIR  
- See: Whirlpool Appliances or  
Authorized Whirlpool Service  
(Example: XYZ Service Co.)

• WASHING MACHINES &  
DRYERS, SERVICE & REPAIR  
- See: Whirlpool Appliances or  
Authorized Whirlpool Service  
(Example: XYZ Service Co.)

### 4. If you need FSP® replacement parts ...

FSP is a registered trademark of Whirlpool Corporation for quality parts. Look for this symbol of quality whenever you need a replacement part for your Whirlpool appliance. FSP replacement parts will fit right and work right, because they are made to the same exacting specifications used to build every new Whirlpool appliance.

To locate FSP replacement parts in your area, refer to Step 3 above or call the Whirlpool Consumer Assistance Center number in Step 2.

### 5. If you are not satisfied with how the problem was solved ...

- Contact the Major Appliance Consumer Action Panel (MACAP). MACAP is a group of independent consumer experts that voices consumer views at the highest levels of the major appliance industry.
- Contact MACAP only when the dealer, authorized servicer and Whirlpool have failed to resolve your problem.  
Major Appliance Consumer Action Panel  
20 North Wacker Drive  
Chicago, IL 60606
- MACAP will in turn inform us of your action.

## **NOTES**

**NOTES**

# WHIRLPOOL®

## Electric Freestanding Range Warranty

ER012

LENGTH OF WARRANTY	WHIRLPOOL WILL PAY FOR
<b>FULL ONE-YEAR WARRANTY</b> From Date of Purchase	FSP® replacement parts and repair labor to correct defects in materials or workmanship. Service must be provided by an authorized Whirlpool <sup>SM</sup> service company.
<b>LIMITED WARRANTY FOR LIFE OF THE PRODUCT</b> Second Year Through Life of Product From Date of Purchase	FSP replacement parts for control knobs.
<b>WHIRLPOOL WILL NOT PAY FOR</b>	
<p><b>A. Service calls to:</b></p> <ol style="list-style-type: none"> <li>1. Correct the installation of the cooking product.</li> <li>2. Instruct you how to use the cooking product.</li> <li>3. Replace house fuses or correct house wiring.</li> <li>4. Replace owner accessible light bulbs.</li> </ol> <p><b>B. Repairs when the cooking product is used in other than normal, single-family household use.</b></p> <p><b>C. Pickup and delivery. This product is designed to be repaired in the home.</b></p> <p><b>D. Damage to the cooking product caused by accident, misuse, fire, flood, acts of God or use of products not approved by Whirlpool.</b></p> <p><b>E. Repairs to parts or systems caused by unauthorized modifications made to the appliance.</b></p>	

**WHIRLPOOL CORPORATION SHALL NOT BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES.** Some states do not allow the exclusion or limitation of incidental or consequential damages, so this limitation or exclusion may not apply to you. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

Outside the United States, a different warranty may also apply. For details, please contact your authorized Whirlpool distributor or military exchange.

If you need service, first see the "Assistance and Service" section of this book. After checking "Assistance and Service," additional help can be found by calling our Consumer Assistance Center telephone number, 1-800-253-1301, from anywhere in the U.S.