


SAFETY INSTRUCTIONS

Information in the Safety Instruction section covers all electric cooking appliances. You may find some information that does not pertain to your particular appliance. Please review this section before using your cooking appliance.


The following instructions are based on safety considerations and must be strictly followed to eliminate the potential risks of fire, electric shock, or personal injury.

PROPER INSTALLATION – Be sure your appliance is properly installed and grounded by a qualified technician.



NEVER USE YOUR APPLIANCE FOR WARMING OR HEATING THE ROOM.

STORAGE ABOVE RANGE – To eliminate the hazard of reaching over hot surface elements, cabinet storage should not be provided directly above a unit. If provided, storage should be limited to infrequently used items that can be safely stored in an area subjected to heat. Temperatures may be unsafe for some items such as volatile liquids, cleaners, or aerosol sprays. If cabinet storage is provided, installation of a range hood that projects at least 5-inches beyond the bottom of the cabinet will reduce the hazards associated with such storage.



WEAR PROPER APPAREL –


Loose-fitting or hanging garments should never be worn while using the appliance.

USER SERVICING – Do not repair or replace any part of the appliance unless specifically recommended in the Use and Care Book. All other servicing should be referred to a qualified technician. Always disconnect unit or cut-off power to unit before any servicing.

STORAGE IN, ON OR NEAR APPLIANCE – Do not store or use gasoline or other flammable materials, vapors and liquids in the oven, near surface units or in the vicinity of this or any other appliance. The fumes can create a fire hazard or explosion. Do not use cooktop or oven as a storage area for food or cooking utensils.

DO NOT USE WATER ON GREASE FIRES –

Smother fire or flame or use dry chemical or foam-type extinguisher, if available or sprinkle heavily with baking soda.




USE ONLY DRY POT HOLDERS – Moist or damp potholders on hot surfaces may result in burns from steam. Do not let potholder touch hot heating elements. Do not use a towel or other bulky cloths.

SURFACE COOKING UNITS:

USE PROPER PAN SIZE – This appliance is equipped with one or more surface elements of different sizes. Select utensils having flat bottoms large enough to cover the surface element. The use of undersized utensils will expose a portion of the heating element to direct contact and may result in ignition of clothing. Proper relationship of utensil to element will also improve efficiency.

NEVER LEAVE SURFACE UNITS UNATTENDED AT HIGH HEAT SETTINGS –

Boilover causes smoking and greasy spillovers that may ignite.



TO PREVENT DAMAGE TO RANGE, never operate a surface unit without a pan in place and never allow a pan to boil dry.

MAKE SURE DRIP BOWLS ARE IN PLACE – Absence of these bowls during cooking may subject wiring or components underneath to damage.

PROTECTIVE LINERS – Do not use aluminum foil to line surface unit drip bowls or oven bottoms, except as suggested in the Use and Care Book. Improper installation of these liners may result in a risk of electric shock, or fire.

SAFETY INSTRUCTIONS

GLAZED COOKING UTENSILS – Only certain types of glass, glass/ceramic, ceramic, earthenware, or other glazed utensils are suitable for range-top service without breaking due to the sudden change in temperature.



UTENSIL HANDLES SHOULD BE TURNED INWARD AND NOT EXTEND OVER ADJACENT SURFACE UNITS – To reduce the risk of burns, ignition of flammable materials, and spillage due to unintentional contact with the utensil, the handle of a utensil should be positioned so that it is turned inward, and does not extend over adjacent surface elements.

DO NOT SOAK REMOVABLE HEATING ELEMENTS – Heating elements should never be immersed in water. Immersing element in water would damage insulating material inside element.

OVENS:

USE CARE WHEN OPENING DOOR – Let hot air or steam escape before removing or replacing food.

DO NOT HEAT UNOPENED FOOD CONTAINERS – Build-up of pressure may cause container to burst and result in injury.

PREPARED FOOD WARNING: Follow food manufacturer's instructions. If a plastic frozen food container and/or its film cover distorts, warps, or is otherwise damaged during cooking, immediately discard the food and its container. The food could be contaminated.

KEEP OVEN VENT DUCTS (located under rear element; rear corner of cooktop; between oven door and control panel of wall oven or on backguard) **UNOBSTRUCTED**. Blockage of vent prevents proper oven air circulation and will affect oven performance. Avoid touching oven vent area while oven is on and for several minutes after oven is turned off. Some parts of the vent and surrounding area become hot enough to cause burns.

PLACEMENT OF OVEN RACKS – Always place oven racks in desired location while oven is cool. If rack must be moved while hot, use care to avoid contact of potholder with oven element.

VENTILATING HOODS:

CLEAN VENTILATING HOODS FREQUENTLY – Grease should not be allowed to accumulate on hood or filter. When flaming foods under the hood, turn the fan off. The fan, if operating, may spread the flame.

IMPORTANT SAFETY NOTICE AND WARNING

The California Safe Drinking Water and Toxic Enforcement Act of 1986 (Proposition 65) requires the Governor of California to publish a list of substances known to the State of California to cause cancer or reproductive harm, and requires businesses to warn customers of potential exposures to such substances.

Users of this appliance are hereby warned that when the appliance is engaged in the self-clean cycle there may be some low-level exposure to some of the listed substances, including carbon monoxide. Exposure to these substances can be minimized by properly venting the appliance to the outdoors during the self-clean cycle.

DEEP FAT FRYERS:

Use extreme caution when moving the grease kettle or disposing of hot grease.

DO NOT TOUCH SURFACE ELEMENTS OR OVEN ELEMENTS, AREAS NEAR ELEMENTS OR INTERIOR SURFACES OF OVEN – Elements may be hot even though they are dark in color. Areas near surface elements and interior surfaces of oven may become hot enough to cause burns. During and after use, do not touch or let clothing or other flammable materials contact heating elements, areas near elements or interior surfaces of oven until they have had sufficient time to cool. Among these areas are the cooktop, surfaces facing the cooktop, oven vent opening and surfaces near this opening, oven door, and oven window. Also, do not allow aluminum foil, meat probes or any other metal object, other than a utensil on a surface element, to contact heating elements.

ANTI-TIP BRACKET:


WARNING: To reduce the risk of tipping of the appliance from unusual usage or by excessive loading of the oven door, the appliance must be secured by a properly installed anti-tip device. To check if device is installed properly: Use a flashlight and look underneath range to see that one of the rear leveling legs is engaged in the bracket slot. When removing appliance for cleaning, be sure anti-tip device is engaged when range is replaced. The anti-tip device secures the rear leveling leg to the floor, when properly engaged.

SAFETY INSTRUCTIONS

ADDITIONAL INFORMATION:

After appliance is installed, be certain all packing materials are removed from the appliance before operating the unit. If appliance is installed near a window, take steps to prevent curtains from blowing over surface elements creating a fire hazard.

Care should be given to location of appliance. Be sure floor covering under appliance, walls adjacent to appliance, cabinetry adjacent to appliance, and other materials adjacent to appliance can withstand prolonged heat. This is a heavy appliance and can settle into soft floor coverings such as cushioned vinyl. Use care when moving range on this type of floor covering.



OVEN DOOR

Do not place excessive weight on an open oven door or stand on an open oven door as, in some cases, it could cause the range to tip over, breakage of the door or serious injury.

CIRCUIT BREAKER OR FUSE – Locate and mark breaker or fuse. Never replace a blown fuse or reset a breaker until you know what has caused the problem. Always replace a blown fuse with one of the correct amperage, do not use a substitute.

CONTROL KNOBS – Turn off control at the completion of a cooking operation.

SELF CLEANING OVEN:

Do not clean door gasket. The door gasket is essential for a good seal. Care should be taken not to rub, damage, or move the gasket. Do not use oven cleaners or oven liner protective coating of any kind in or around any part of the self clean oven. Clean only parts listed in this booklet. Before self cleaning the oven, remove broiler pan, oven racks, and other utensils.

CAUTION: DO NOT LEAVE FOOD OR COOKING UTENSILS, ETC., IN OVEN DURING THE SELF CLEANING MODE OF OPERATION.

ATTENTION: NE LAISSEZ AUCUN ALIMENT, UTENSILE DE CUISINE, ETC., DANS LE FOUR DURANT LE CYCLE D'AUTONETTOYAGE.


On some models, a fan should be heard during the self clean cycle. If not, cancel clean cycle and call a serviceman before self cleaning again. (Refer to CONTENTS on front cover for location of self clean instructions and fan information.)

SMOOTHTOP COOKTOP:

Do not cook on broken cooktop. If cooktop should break, cleaning solutions and spillovers may penetrate the broken cooktop and create a risk of electric shock. Contact a qualified technician immediately. Clean cooktop with caution. If a wet sponge or cloth is used to wipe spills on a hot cooking area, be careful to avoid steam burn. Some cleaners can produce noxious fumes if applied to a hot surface.

DO NOT LEAVE CHILDREN ALONE – Children should not be left alone or unattended in area where appliance is in use. They should never be allowed to sit or stand on any part of the appliance. CAUTION: Do not store items of interest to children in cabinets above an appliance or on the backguard of a range.

Children climbing on the appliance to reach items could be seriously injured. Children must be taught that the appliance and utensils in or on it can be hot. Children should be taught that an appliance is not a toy. They should not be allowed to play with controls or other parts of the unit.



IN CASE OF FIRE:

1. Turn off appliance and ventilating hood.
2. Use dry or foam-type extinguisher or baking soda to smother flame. Never use water on a grease fire.
3. If fire is in oven, smother by closing oven door.
4. If fire is in a pan on the surface unit, cover pan.

This appliance has been tested for safe performance using conventional cookware. Do not use any devices or accessories that are not specifically recommended in this manual. Do not use eyelid covers for the surface units, stove top grills, or add-on oven convection systems. The use of devices or accessories that are not expressly recommended in this manual can create serious safety hazards, result in performance problems, and reduce the life of the components of the appliance.

–SAVE THESE INSTRUCTIONS–

FEATURES

If your range features a time-of-day clock and timer follow the instructions for the illustration that match the clock on your range.



88:88 will flash in the display when range is first connected to power or if power is interrupted. The display will stop flashing once the time-of-day clock has been set.


TO SET CLOCK: Press and hold CLOCK SET button while turning MINUTE TIMER knob to the correct time-of-day. MINUTE TIMER knob can be turned in either direction.

TO SET MINUTE TIMER: Turn MINUTE TIMER knob to the right, to the desired time, up to 60:00 (1 hour). Timer will begin counting down after a few seconds delay. When time has lapsed, a continual beep will sound for up to 2 minutes.

Press CLOCK SET button to stop beep sounds. The correct time-of-day will reappear in the display.

To cancel the timer: Turn MINUTE TIMER knob to the left, until 00:00 appears in the display. The correct time-of-day will reappear in the display after a few seconds delay.

To check time-of-day during a timing operation, press and hold CLOCK SET button. Time will reappear in the display.



12:00 will flash in the display when the range is first connected to power or if power is interrupted. The display will stop flashing once the time-of-day clock has been set.

TO SET CLOCK:

1. Slide switch up to CLOCK position.
2. Press and hold the HOUR pad until the correct hour appears in the display.
3. Press and hold the MIN pad until the correct minutes appear in the display.

TO SET TIMER:

1. Slide switch down to the TIMER position. 0:59 (or one hour) will appear in the display.

The timer will automatically begin counting down in increments of one minute.


2. To set timer for less than one hour: Slide the switch down to the TIMER position then press and hold the MIN pad until the desired time appears in the display.
3. To set timer for more than one hour: (Two hours is the maximum time that can be set.)

Slide the switch down to the TIMER position then press the HOUR pad. 1:59 (or two hours) will appear in the display.

Press the MIN pad until the desired minutes appear in the display.

4. When the timer has counted down, 0:00 will appear in the display and continuous beeps will sound. Press the CLOCK pad to cancel the beeps. The current time of day will reappear in the display.

To cancel the timer: Slide the switch up to the clock position and the display will return to the time of day.



12:00 will flash in the display when the range is first connected to power or if power is interrupted. The display will stop flashing once the time-of-day clock has been set.

TO SET CLOCK:

1. Press the CLOCK pad.
2. Press and hold the HOUR pad until the correct hour appears in the display.
3. Press and hold the MINUTE pad until the correct minutes appear in the display.

TO SET TIMER:

1. Press the TIMER pad. 0:59 (or one hour) will appear in the display.

The timer will automatically begin counting down in increments of one minute.

2. To set timer for less than one hour: Press the TIMER pad then press and hold the MINUTE pad until the desired time appears in the display.
3. To set timer for more than one hour: (Two hours is the maximum time that can be set.)

Press the TIMER pad then press the HOUR pad. 1:59 (or two hours) will appear in the display.

Press the MINUTE pad until the desired minutes appear in the display.

4. When the timer has counted down, 0:00 will appear in the display and continuous beeps will sound. Press the CLOCK pad to cancel the beeps. The current time of day will reappear in the display.

To cancel the timer: Press the CLOCK pad and the display will return to the time of day.

FEATURES

CONTINUOUS CLEANING OVEN (if equipped)

WHAT IS THE CONTINUOUS CLEANING OVEN?

The finish of the Continuous Cleaning Oven is identified by its dark gray color, white stipple and rough, porous texture. The rough texture prevents grease spatters from forming beads which run down the walls leaving unsightly streaks. Rather, the rough texture absorbs spatters and allows them to spread, thus exposing a larger area to the hot oven air. The catalyst, when exposed to heat, speeds the oxidation of soil.

Cleaning action automatically begins whenever the oven is turned on for baking or roasting. The oven MUST be "on" for cleaning to take place. No cleaning will occur when the oven is off. The special catalytic finish must be exposed to hot oven air before soil will begin to gradually reduce in size.

FACTORS AFFECTING LENGTH OF CLEANING TIME

The higher the oven temperature, the faster the cleaning action. The length of cleaning time will depend on these factors: Type of soil, amount or size of soil, oven temperature and length of time oven is in use. Time may vary from a few minutes to several hours. Soil deposited at the end of a cycle may still be visible. This will usually fade with continued oven use until the soil gradually disappears or can be wiped up manually. The oven will appear presentably clean, even though some spatters may be present.

MANUALLY CLEANING HEAVY SPILLOVERS

The special finish will clean most spatters during normal oven use unless there is a heavy buildup of soil. Heavy spillovers such as pie or casserole boilovers will not clean effectively without some manual help. The crusty or varnish-like stains that form from these spillovers clog the pores and prevent the special finish from being exposed to the hot oven air. This greatly reduces the cleaning effectiveness of the finish.

These crusty or varnish-like stains must either be removed or broken up before cleaning can effectively take place.

TO MANUALLY CLEAN HEAVY SPILLOVERS

Brush off heavy soil with a nylon brush or plastic pad. DO NOT USE paper towels, cloths or sponges for the oven walls are porous and particles of these materials will rub off on the walls. Rinse area with clear water only.



HINTS

Brittle crusts or stains can be loosened by GENTLY tapping stain with a wooden or plastic utensil. Brush away any loose soil that flakes off. Varnish type stains usually need to be softened with a small amount of water or damp cloth. Remaining soil will gradually reduce with continued oven use at normal baking temperatures.

DO NOT USE ANY TYPE OF OVEN CLEANER, POWDERED CLEANSERS, SOAP, DETERGENT OR PASTE ON ANY CONTINUOUS CLEANING SURFACE. ALSO, DO NOT USE ANY ABRASIVE MATERIALS, STEEL WOOL, SHARP INSTRUMENTS OR SCRAPERS FOR THEY WILL DAMAGE THE FINISH.


Avoid spillovers by using utensils that are large enough to hold food. A cookie sheet or piece of aluminum foil, just a little larger than the pan, can be placed on the rack directly below the rack holding the utensil to catch spills.

Over a period of time, wear marks may appear on the embossed rack supports. This is normal and results from sliding the racks in and out of the oven. Wear marks will not affect the cleaning action of the oven.

USING YOUR SMOOTHTOP

COOKING AREAS


The four surface cooking areas on your range are identified by permanent patterns in the cooktop. There are two large and two small areas. Use the smaller areas for small cooking utensils and the larger areas for large utensils. This conserves energy.



When a cooking area is turned ON, the coil element under the cooktop will heat up and glow red. The element will cycle on and off to maintain the heat setting. When the element cycles on, it is normal to see a red glow through the smoothtop.

SURFACE CONTROLS


The cooking area controls are called INFINITE controls. This type of control provides an infinite choice of heat settings from LOW to HIGH. The control can be set either on any of the numbered settings or between the numbered settings.



Knobs on your range may not look like this knob but they operate as described in this booklet.

Always place pan on the surface element before turning element on as heat from exposed element may damage backguard or range parts.

To operate: Push in and turn knob, in either direction, to the desired heat setting.



SIGNAL LIGHTS

Ranges are equipped with one to four signal lights to indicate when a surface element is on. The light will remain on until the element is turned off. After a cooking operation, be sure element and signal light are off.

HOT SURFACE LIGHT

The range is equipped with a HOT SURFACE light. This red light will turn on to indicate that the cooking area is hot and will remain on until the area has cooled.

RETAINED HEAT

The smoothtop cooking area retains heat for a period of time after the element has been turned off. Put this residual heat to good use. Turn the element off a few minutes before food is completely cooked and use the retained heat to complete the cooking operation. After 30 minutes, the cooktop may be too cool to keep foods warm; however, the TOP MAY STILL BE TOO WARM TO TOUCH. When the HOT SURFACE indicator light turns off, the top will be cool enough to touch.

We suggest that you start with a lower heat setting then gradually increase the setting until you find the optimum setting. Boilovers are more likely to occur if you start out on HIGH then reduce to the lower setting.

HINTS

If food is cooking too fast or if boilovers occur, remove lid and reduce to a lower setting. Allow enough time for the cooking area to adjust to the new setting.

To help keep cooktop clean be sure cooking area and utensil bottom are clean and dry before use.

Do not allow plastic objects, aluminum foil, sugar, or foods with high sugar content to melt onto the hot cooktop. Melted materials can cause permanent damage to the cooktop.

IMPORTANT: Watch sugary solutions carefully to avoid boilover. If sugar solution (such as jam, jelly, candy) is allowed to boilover, it may pit the glass. Turn element to LOW and clean sugary boilovers **immediately**. Use a wooden-handled metal spatula to scrape boilover to a cooler area of the cooktop or use several layers of dry paper towels to wipe up spillover. If a paper towel is used, be careful to avoid steam burns. Turn element off. When cool, use a single-edge razor blade such as Widget by Gillette to scrape off soil. Clean with Elico Cooktop Cleaning Creme, rinse and dry.

To protect the top, it is not recommended to use the top as a work surface or as a cutting board or to cook food directly on the cooktop without a utensil.

Do not use a trivet or metal stand (such as a wok ring) between the utensil and the cooktop. These items can mark or etch the surface and affect cooking efficiency.

Thin gauge aluminum cookware, aluminum foil or foil containers such as popcorn poppers are NOT recommended for use on the cooktop. They will leave metal marks.

Do not slide glass items across the cooktop. They may scratch or damage the top.

Do NOT slide aluminum cookware across the cooktop. This may result in aluminum marks which then must be immediately removed with a recommended cooktop cleaner.

USING YOUR SMOOTHTOP

COOKWARE

Cooking performance is greatly affected by the type of cookware used. Pans should have a flat bottom. The flat bottom allows good conductivity between the utensil and the cooking area to provide uniform cooking results, faster heating and more efficient use of energy.

Pans with uneven, warped, or grooved bottoms do not make good contact, reduce heat conductivity and result in slower, less even heating.

Be sure utensil is large enough to properly contain food and avoid boilovers.

Pan size is particularly important in deep frying. Be sure pan will accommodate the volume of food that is to be added as well as the bubble action of fat. **Never leave a deep fat frying operation unattended.**

Acceptable water-bath or pressure canners should not be oversized and must have a flat bottom.

Do not use specialty items that are oversized, have an uneven bottom or do not meet proper utensil specifications.

SPECIAL PRECAUTIONS FOR COOKING UTENSILS:

- **Aluminum foil** will damage the smoothtop if it melts onto the glass. Do not use aluminum foil or foil-type containers under any circumstances.
- **Aluminum utensils** will cause metal marks on the glass if you slide them across the ceramic cooktop. Remove any metal marks immediately.
- **Glass, ceramic, earthenware, heat-proof glass or glazed utensils** may scratch the smoothtop cooktop if you slide them across the top.

SUGGESTED HEAT SETTINGS

Use the following chart as a **GUIDELINE** until you become more familiar with your cooktop. Keep in mind that different types of cookware materials require different heat settings for the same cooking operation.

We suggest that you experiment to find the heat setting that best suits your particular cooking needs. Chart is based on heavy gauge aluminum cookware. Lower the heat setting if using other materials.

| HEAT SETTINGS | USES |
|----------------------------|---|
| HI | To bring liquid to a boil, blanch, preheat skillet, or bring pressure up in pressure cooker. (Note: Always follow instructions in pressure cooker use and care book.) Always reduce to a lower heat setting when liquids just begin to boil or food begins to cook. |
| Medium-High 9 8 7 | To brown or sear meat, heat oil for deep fat frying, scald. To fast saute or fry. Maintain fast boil for large amounts of liquids. For slower frying or sauteing operation. |
| Medium 6-5 | To maintain moderate to slow boil for large amounts of liquids. |
| Medium-Low 4 3 2 | To continue cooking uncovered foods and for most frying operations. To continue cooking covered foods and to maintain boil pressure in most pressure cookers. Stew, braise or steam operations. To maintain boil for small amounts of liquid, poach, steam or simmer. |
| LO | To keep foods warm before serving. |

NOTE: Refer to cookware manufacturer's recommendations for suggested heat settings. Some manufacturers do not recommend the use of HIGH or the use of HIGH for extended cooking operations.

USING YOUR SMOOTHTOP

CARE INFORMATION

Clean smoothtop after each use. Use only cleaning agents recommended in the cleaning chart. Other materials may damage the finish of the smoothtop.

Carefully blot up spillovers around the outside of the cooking area as they occur with dry paper towels. BE CAREFUL NOT TO BURN HANDS WHEN WIPING UP SPILLS. DO NOT USE A DAMP CLOTH WHICH MAY CAUSE STEAM BURNS.

When surface is cool, clean as directed in the chart. **DO NOT USE** the following cleaning agents.

- Abrasives (metal scouring pads, cleansing powders, scouring cleaners or pads) will scratch the smoothtop.
- Chemicals (oven cleaners, chlorine bleaches, rust removers or ammonia) may damage the finish of the smoothtop.
- Cleaning agents designed for glassware which contain ammonia may harm the smoothtop.
- Soiled cloth or sponge will leave an invisible film on the cooktop which may cause discoloration the next time the cooktop is used.

CAUTION:

If metal melts onto the smoothtop, **DO NOT USE TOP. CALL AN AUTHORIZED SERVICER.** Do not attempt to repair cooktop yourself.

To prevent permanent damage to the cooktop, do not allow cookware to boil dry.

Do not place plastics on a warm or hot cooking area. They will melt and adhere to the smoothtop. The smoothtop may chip or pit in attempting to remove melted plastic from the top.

To prevent scratching or damage to the smoothtop: Do not leave sugar, salt, sand, soil, shortening or other fats on the cooking area. Be sure area is free from these before turning on cooking area.

CLEANING CHART

WARNING: BEFORE CLEANING, BE CERTAIN ALL ELEMENTS ARE TURNED OFF AND THE COOKTOP IS COOL.

| | | |
|--|--|--|
| Daily cleaning, light to moderate stains. | Elco Cooktop Cleaning Creme. Liquid dishwashing detergent. Paste of baking soda and water. | Gently apply with a non abrasive plastic brush, nylon or plastic pad, or paper toweling, rinse completely and dry. |
| Heavy stains, burned on food. | Elco Cooktop Cleaning Creme. Paste of baking soda and water. | Gently scour with paste and paper towel to remove as much as possible. Then reapply paste and let stand for 30 to 45 minutes. Cover with damp paper toweling to keep paste moist. Scour to remove remaining stain. Rinse completely and dry. |
| Burned on or crusty soil. | Single-edge razor blade such as Widget by Gillette. | When cooktop is cool. Place edge of single edge razor on ceramic cooktop at a 30° angle. Very CAREFULLY scrape off soil. Clean remaining soil with Elco Cooktop Cleaning Creme. |
| Brown or gray stains from HARD WATER or metal marks. | Elco Cooktop Cleaning Creme. | Gently scour with paste to remove as much as possible. Reapply paste and let stand for 30 minutes. Scour with additional paste to remove remaining stain. Rinse completely and dry. |

PROBLEM SOLVING CHART

| PROBLEM | CAUSE | TO PREVENT |
|--|--|---|
| Tiny scratches or abrasions | Coarse particles (dust salt and sand) between cookware bottom and cooktop. Incorrect cleaning materials. Sliding glassware or metal across top or using cookware with rough bottoms. | Tiny scratches are not removable and do not affect cooking. In time, the scratches will become smoother and less visible. Be sure cookware bottoms and cooktop are clean before use. Use cookware with a smooth, non-scratching bottom. Do not slide cookware across cooktop. |
| Metal-marking | Sliding or scraping metal utensils or oven racks across cooktop. | Do not slide metal object across cooktop. Clean immediately with Elco Cooktop Cleaning Creme. |
| Brown streaks and specks | Boilovers, incorrect cleaning materials, used soiled cloth or sponge, soiled cookware. | Remove boilovers before reusing the cooktop. Use a clean cloth or sponge. Be sure cookware, especially bottoms, are clean and dry. |
| Areas of discoloration with a metallic sheen | Mineral deposits from water and foods. | Use cookware with bottoms that are clean and dry. Use correct heat setting to prevent boilovers. |
| Pitting or flaking | Sugary boilovers from sugar syrups, candy, jams, jellies, dessert sauces, etc. | Use correct heat setting and large enough utensil. Watch cooking operation to prevent boilovers or spattering. See "HINTS" on page 7 for cleaning instructions. |


USING YOUR OVEN

OVEN

CHARACTERISTICS

Every oven has its own characteristics. You may find that the cooking times and temperatures you were accustomed to with your previous range may need to be altered slightly with your new range. Please expect some differences with this new range.

OVEN CONTROLS



The THERMOSTAT knob is used to select and maintain the oven temperature. Always turn this knob just TO the desired temperature. Do not turn to a higher temperature and then back. On some models, there is an indent at the 350°F setting.

The SELECTOR knob determines the type of oven operation. Turn this knob to desired setting. Each setting is identified by an indent (stop) and a "click" sound.

To turn the oven on, **both** the Thermostat and Selector knobs must be set. The oven will not operate if the Selector knob is left in the OFF position. To turn the oven off, turn the selector knob to the OFF position.

OVEN INDICATOR LIGHT

The OVEN indicator light, located on the backguard, turns on whenever the selector knob is turned to BAKE or BROIL. When the oven reaches the preset temperature, the indicator light turns off and on as the oven elements cycle off and on.

OVEN RACKS

The two oven racks are designed with a "lock-stop" position to keep racks from accidentally coming completely out of the oven.

To remove: Be sure rack is cool. Pull rack out to the "lock-stop" position. Tilt up and continue pulling until rack releases.

To replace: Place rack on rack supports, tilt up and push toward rear of oven. Pull rack out to "lock-stop" position to be sure rack is correctly replaced.

RACK POSITIONS:


RACK 1 (top of oven) used for broiling thin non-fatty foods such as fish.

RACK 2 used for two-rack baking or broiling thicker cuts of meat.

RACK 3 used for most one-rack baking and for roasting some meats.

RACK 4 used for one or two rack baking and roasting large meats, cooking larger foods and for baking angel food cake or pie shells.


RACK 5 used for roasting turkey or baking angel food cake or pie shells.



Use racks 2 and 4 when baking layer cakes. Use racks 2 and 5 when baking cookies and biscuits on a cookie sheet.

HINTS

If cooking on two racks, stagger pans so one is not directly over the other. Use rack positions 2 and 4 or 2 and 5, when cooking on two racks.



For optimum baking results of cakes, cookies or biscuits, use one rack. Position rack so food is in the center of the oven. Allow 2 inches between edge of utensil and the oven sides or adjacent utensils.

NEVER place pans directly on the oven bottom.

Do not cover entire rack with aluminum foil or place foil directly under cookware. To catch spillovers, cut a piece of foil a little larger than the pan and place it on the rack below the rack containing the pan.

PREHEATING

Preheating is necessary for baking. Allow oven to heat for 10 to 15 minutes before adding food. It is not necessary to preheat oven for roasting.

It is not necessary to preheat for broiling unless darker browning is desired or if cooking thin (3/4-inch) steaks. Allow broil element to preheat 3 to 5 minutes.

Selecting temperature higher than desired will NOT preheat the oven any faster. Preheating at a higher temperature may have a negative effect on baking results.

USING YOUR OVEN

HOW TO SET OVEN:

1. When cool, position rack in oven.
2. Turn thermostat knob to desired temperature.
3. Turn selector knob to BAKE.
4. Place food in center of oven, allowing a minimum of 2 inches between utensil and oven walls.
5. Check food for doneness at minimum time in recipe. Cook longer if necessary.
6. Remove food from the oven and turn the selector knob to OFF.

COMMON BAKING PROBLEMS AND WHY THEY HAPPEN

| PROBLEM | CAUSE | PROBLEM | CAUSE |
|---|--|---|---|
| Cakes are uneven. | Pans touching each other or oven walls. Batter uneven in pans. Temperature set too low or baking time too short. Oven not level. Undermixing. Too much liquid. | Cakes don't brown on top. | Incorrect rack position. Temperature set too low. Overmixing. Too much liquid. Pan size too large or too little batter in pan. Oven door opened too often. |
| Cake high in middle. | Temperature set too high. Baking time too long. Overmixing. Too much flour. Pans touching each other or oven walls. Incorrect rack position. | Excessive shrinkage. | Too little leavening. Overmixing. Pan too large. Temperature set too high. Baking time too long. Pans too close to each other or oven walls. |
| Cake falls. | Too much shortening or sugar. Too much or too little liquid. Temperature set too low. Old or too little baking powder. Pan too small. Oven door opened frequently. Added incorrect type of oil to cake mix. Added additional ingredients to cake mix or recipe. | Uneven texture. | Too much liquid. Undermixing. Temperature set too low. Baking time too short. |
| Cakes, cookies, biscuits don't brown evenly. | Incorrect rack position. Oven door not closed properly. Door gasket not sealing properly. Incorrect use of aluminum foil. Oven not preheated. Pans darkened, dented, warped, or large cookie sheet. | Cakes have tunnels. | Not enough shortening. Too much baking powder. Overmixing or at too high a speed. Temperature set too high. |
| For optimum results, bake on one rack. If baking cakes on two racks, place pans toward front of oven on upper rack and pans toward back of oven on lower rack. | | Cakes crack on top. | Batter overmixed. Temperature set too high. Too much leavening. Incorrect rack position. |
| Cakes, cookies, biscuits too brown on bottom. | Oven not preheated. Pans touching each other or oven walls. Incorrect rack position. Incorrect use of aluminum foil. Placed 2 cookie sheets on one rack. Used glass, darkened, stained, warped or dull finish metal pans. (Use a shiny cookie sheet.) | Cake not done in middle. | Temperature set too high. Pan too small. Baking time too short. |
| Follow cookware manufacturer's instructions for oven temperature. Glassware and dark cookware such as Ecko's Baker's Secret require lowering the oven temperature by 25° F. | | If additional ingredients were added to mix or recipe, expect cooking time to increase. | |
| | | Pie crust edges too brown. | Temperature set too high. Pans touching each other or oven walls. Edges of crust too thin. |
| | | Pies don't brown on bottom. | Used shiny metal pans. Temperature set too low. |
| | | Pies have soaked crust. | Temperature too low at start of baking. Filling too juicy. Used shiny metal pans. |

USING YOUR OVEN

HOW TO BROIL

Broiling is a method of cooking tender meats by direct heat under the element. The cooking time is determined by the distance between the meat and the element, the desired degree of doneness and the thickness of the meat.

Broiling requires the use of the broiler pan and insert. The correct position of the insert in the pan is very important. The broiler insert should be placed in the pan so grease will drain freely. Improper use may cause grease fires.


The broiler insert CANNOT be covered with aluminum foil as this prevents fat from draining into pan below. However, for easier cleaning, the broiler pan can be lined with foil.

Do not use disposable broiler pans. They do not provide a separate tray.

Preheat broil element 5 to 10 minutes if darker browning is desired.

TO BROIL:

1. Remove excess fat and slash remaining fat. To help keep meat from curling.
2. Place broiler pan on the recommended rack position. For brown exterior and rare interior, the meat should be close to the element. Place further down if you wish meat well done. Excessive smoking may occur if meat is placed too close to the broil element.
3. To set oven: Turn both the thermostat and selector knobs to BROIL.



4. Broiling should be done with oven door opened to the broil "STOP" position (opened about 4 inches.).
5. Follow suggested times on broiling chart. Meat should be turned once about half way through cooking.
6. Check doneness by cutting a slit in meat near center for desired color.
7. Turn the selector knob to OFF after cooking.

Broil times may need to be increased if range is installed on a 208-volt circuit.

BROILING CHART

| TYPE OF FOOD | RACK POSITION | DONESS | TOTAL TIME |
|---|----------------|--|--|
| BACON | #2 | Well Done | 6 to 10 minutes |
| BEEF STEAKS 1-inch thick | #2 #2 #2 | Rare Medium Well Done | 10 to 14 minutes 15 to 18 minutes 19 to 22 minutes |
| 1 1/2-inch thick | #2 #2 #3 | Rare Medium Well Done | 18 to 20 minutes 22 to 24 minutes 25 to 30 minutes |
| CHICKEN Whole, split Pieces | #3 #3 | Well Done Well Done | BROIL AT 450°F 45 to 60 minutes 30 to 45 minutes |
| FISH STEAK OR FILLET 1/2-inch thick | #2 | Flaky | 10 to 12 minutes |
| GROUND BEEF PATTIES 3/4 to 1-inch thick | #2 | Rare Medium Well Done | 10 to 13 minutes 12 to 15 minutes 15 to 18 minutes |
| HAM SLICE, precooked 1-inch thick 1 1/2-inch thick | #2 #2 | | 12 to 16 minutes 21 to 26 minutes |
| LAMB CHOPS 1-inch thick 1 1/2-inch thick | #2 #3 | Medium Well Done Medium Well Done | 12 to 15 minutes 16 to 20 minutes 15 to 19 minutes 25 to 30 minutes |
| PORK CHOPS 3/4-inch thick 1-inch thick | #2 #2 | Well Done Well Done | 15 to 20 minutes 20 to 25 minutes |
| WIENERS, precooked Hot dogs, smoked or Polish sausage, Bratwurst, etc. | #2 | | 8 to 12 minutes |

MAINTENANCE

LIGHT REPLACEMENT

Before replacing oven light bulb, DISCONNECT POWER TO RANGE. Be sure bulb is cool. Do not touch a hot bulb with a damp cloth as the bulb may break.


Very carefully remove bulb with a dry potholder to prevent possible harm to hands. Replace with a 40 watt appliance bulb. Reconnect power to range and reset clock, if equipped.

STORAGE DRAWER

The storage drawer at the bottom of the range is safe and convenient for storing metal and glass cookware. DO NOT store plastic, paperware, food or flammable material in this drawer. Remove drawer to clean under range.

To remove: Empty drawer then pull drawer out to the first stop position. Lift up front of drawer and pull to the second stop position. Grasp sides and lift up and out to remove drawer.

To replace: Fit ends of drawer glides onto rails. Lift up drawer front and gently push in to first stop position. Lift up drawer again and continue to slide drawer to the closed position.




OVEN DOOR

Do not place excessive weight on an open oven door or stand on an open oven door as, in some cases, it could cause the range to tip over, breakage of the door or serious injury.

When opening oven door, allow steam and hot air to escape before reaching in oven to check, add or remove food.

To remove lift-off door: Open door to the "stop" position (opened about 4 inches) and grasp door with both hands at each side. Do not use door handle to lift door. Lift up evenly until door clears the hinge arms.



CAUTION:


Hinge arms are spring mounted and will slam shut against the range if accidentally hit. **Never place hand or fingers between the hinges and the front oven frame.** You could be injured if hinge snaps back.

To replace door: Grasp door at each side, align slots in the door with the hinge arms and slide door down onto the hinge arms until completely seated on hinges.

Do not attempt to open or close door until door is completely seated on hinge arms. Never turn on oven unless door is properly in place. When baking, be sure door is completely closed. Baking results will be affected if door is not securely closed.

LEVELING LEGS

Some floors are not level. For proper baking, your range must be level. Leveling legs are located on each corner of the base of the range. Level by turning the legs.




To prevent range from accidentally tipping, range should be secured to the floor by sliding rear leveling leg into the anti-tip bracket supplied with the range.

FUSES

(Canadian Models Only)

Your range is equipped with seven (7) type "P" fuses. The fuses are located on the back wall. Remove the storage drawer for access to the fuses.



If part of your range does not operate, check to see if a fuse has blown. A gap in the fuse strip or a darkened window indicates a blown fuse. Replace with the same type and amperage type "P" fuse.

CARE AND CLEANING

| PARTS | CLEANING AGENTS | DIRECTIONS Be sure all parts are cool before cleaning. Be sure all parts are properly replaced after cleaning. |
|---|--|---|
| Broiler pan & insert | Soap & water. Plastic scouring pad. Soap filled scouring pad. | Remove from oven after use. Cool then pour off grease. Place soapy cloth over insert and pan; let soak to loosen soil. Wash in warm soapy water. Use soap filled scouring pad to remove stubborn soil. Clean in dishwasher if desired. |
| Baked Enamel: Side panels Backguard Oven door Storage drawer | Soap & water. Paste of baking soda & water. | Use a dry paper towel or cloth to wipe up spills, especially acid spills, as soon as they occur. (This is especially important for white surfaces.) When surface is cool, wash with soap and water. Do not use abrasive or harsh cleaning liquids and powders or oven cleaners. These will scratch and permanently damage the finish. Dry with a soft cloth. |
| Control knobs | Mild detergent & water. | To remove knobs, gently pull forward. Wash in mild detergent and water. Do not use abrasive cleaning agents. They will scratch finish and remove markings. Rinse, dry and replace. Turn each element ON to see if knobs have been replaced correctly. |
| Glass: Backguard Oven window Smoothtop, see page 8 | Soap & water. Paste of baking soda & water. Window cleaning fluid. | Wash with soap and water. Remove stubborn soil with paste of baking soda and water. Do not use abrasive materials such as scouring pads, steel wool or powdered cleaning agents. They will damage glass. Rinse with clear water and dry. To prevent staining of oven window, never use excessive amounts of water which may seep under or behind glass. |
| Metal finishes: Aluminum - backguard base. Chrome & stainless steel - trim parts | Soap & water. Paste of baking soda & water. | Wash with soap and water. Remove stubborn soil with paste of baking soda and water. Do not use oven cleaners, abrasive or caustic agents. They will damage the finish. |
| Oven racks | Soap & water. Cleaning powders & plastic pads. Soap filled scouring pad. | Clean with soapy water. Remove stubborn soil with cleansing powder or soap filled scouring pad. Rinse and dry. |
| Plastic finishes: Door handle, Trim, Backguard trim, Overlay, Knobs, or End caps | Soap & water. Paste of baking soda and water. Non-abrasive plastic pad or sponge. | Do not use oven cleaner, powder or liquid cleansers, abrasive or caustic cleaning agents on plastic finishes. These cleaning agents will scratch or marr finish. To prevent staining or discoloration, wipe up fat, grease or acid (tomato, lemon, vinegar, milk, fruit juice, marinade) immediately with a dry paper towel or cloth. When surface is cool, clean with soap and water; rinse, and dry. |
| Porcelain enamel: Oven interior See page 5 for continuous clean oven. | Mild liquid cleaners, detergent or soap & water. Cleansing powders and non abrasive nylon or plastic pads. Do not use oven cleaner on continuous clean oven. | Porcelain enamel is glass fused on metal. It may crack or chip with misuse. Clean with soap and water when parts are cool. All spillovers, especially acid or sugar spillovers, should be wiped up immediately with a dry cloth. Surface may discolor or dull if soil is not removed. When surface is cool, clean with warm soapy water. NEVER WIPE OFF A WARM OR HOT ENAMEL SURFACE WITH A DAMP CLOTH. THIS MAY CAUSE CRACKING AND CHIPPING. Never use abrasive or caustic cleaning agents on exterior finish of range. Use commercial oven cleaner on porcelain - lined oven ONLY. Carefully read and follow manufacturer's instructions. |
| Silicone rubber door gasket | Soap & water. | Door gasket is located on the door plug. DO NOT REMOVE GASKET. Wash with soap. Rinse thoroughly. |
| Oven Elements | | Elements are self cleaning. Soil will burn off as elements are used. Do not spray oven cleaner on elements, electrical hook up or connection. |

SERVICE

| PROBLEM | SOLUTION |
|--|--|
| PART OR ALL OF YOUR RANGE DOES NOT OPERATE | Is the range plug disconnected from the electrical outlet? • Are house fuses blown or circuit breakers tripped? • Is the range plug loose or improperly plugged in? Has power supply to your home been interrupted? • Was oven properly set? |
| SURFACE ELEMENTS FAIL TO TURN ON OR HEAT FOOD PROPERLY | Is range plug disconnected from the electrical outlet? Check circuit breaker or fuse box for tripped circuit breakers or blown fuses. • Is element properly plugged into receptacle? • Was incorrect pan used? For optimum results, pan SHOULD HAVE A FLAT bottom. See pages 6 and 7 for additional information. (NOTE: Expect cooking times to increase if range is connected to 208 volts). • Have serviceman check element. |
| FOOD NOT BAKING SATISFACTORILY | Are racks properly in place and in correct position for what you are baking? • Is range level? • Are you using the proper pan? Is it bright, not soiled or dark colored? • Have you used foil incorrectly? • Are you using standard measuring utensils? • Did you preheat if recommended? • Oven temperature is incorrectly set – too low or too high. See Common Baking Problem chart on page 10. |
| OVEN DOES NOT OPERATE | Is the range disconnected from the electrical power? • Was the Selector knob turned to bake or broil? • Was oven properly set? |
| OVEN LIGHT DOES NOT WORK | Is bulb loose or burned out? |

SERVICE

Do not attempt to service the appliance yourself unless directed to do so in this book. Contact the dealer who sold you the appliance for service.

HOW TO OBTAIN SERVICE

When your appliance requires service or replacement parts, contact your Dealer or Authorized Servicer. Use only genuine factory or Maycor parts if replacement parts are necessary. Consult the Yellow Pages in your telephone directory under appliance for the service center nearest you. Be sure to include your name, address, and phone number, along with the model and serial numbers of the appliance. (See front

cover for location of your model and serial numbers.)

If you are unable to obtain service, write to us. Our address is found on the rating plate. See front cover for location of rating plate.

If you are not satisfied with the local response to your service requirements, call or write MAYCOR Appliance Parts and Service Company, 240 Edwards Street, S.E., Cleveland, TN 37311, (615) 472-3500. Include or have available the complete model and serial numbers of the appliance, the name and address of the dealer from whom you purchased the appliance, the date of purchase and details concerning your problem.

If you did not receive satisfactory service through your servicer or Maycor you may contact the Major Appliance Consumer Action Panel by letter including your name, address, and telephone number, as well as the model and serial numbers of the appliance.

Major Appliance Consumer Action Panel
20 North Wacker Drive
Chicago, IL 60606

MACAP (Major Appliance Consumer Action Panel) is an independent agency sponsored by three trade associations as a court of appeals on consumer complaints which have not been resolved satisfactorily within a reasonable period of time.

COOKING APPLIANCE

ONE YEAR - FULL WARRANTY

Maycor Appliance Parts and Service Company will repair or replace, without charge, any part of your appliance which has a defect in material or workmanship during the first year after the date of the original installation. This warranty extends to any owner during the one year warranty period when the appliance is located in the United States or Canada.

ADDITIONAL FOUR YEAR - LIMITED WARRANTY

For an additional four year period beyond the first year of the FULL warranty coverage:

- Maycor will replace, at no charge, any smoothtop heating element, solid disc heating element, or gas sealed surface burner which fails to heat as a result of defective workmanship or materials.
- Maycor will replace, at no charge, any smoothtop cooking surface which cracks or breaks during the normal household cooking.

These parts must be installed by an authorized Maycor servicer. Any labor charge required for replacement is NOT covered by this limited warranty. This warranty extends to any owner during the additional four year warranty period when the appliance is located in the United States or Canada.

WHAT IS NOT COVERED BY THESE TWO WARRANTIES:

1. Conditions and damages resulting from any of the following:
 - a. Improper installation, delivery, or maintenance.
 - b. Any repair, modification, alteration or adjustment not authorized by Maycor, or a Maycor authorized servicer.
 - c. Misuse, abuse, accidents or unreasonable use.
 - d. Incorrect electrical current, voltage or supply.
 - e. Improper setting of any control.
2. Warranties are void if the original serial numbers have been removed, altered, or cannot be readily determined.
3. Light bulbs.
4. Products purchased for commercial or industrial use.
5. The cost of service or service call to:
 - a. Correct installation errors.
 - b. Instruct the consumer on the proper use of the product.
 - c. Transport the appliance to a servicer.
6. CONSEQUENTIAL OR INCIDENTAL DAMAGES SUSTAINED BY ANY PERSON AS A RESULT OF ANY BREACH OF THESE WARRANTIES. Some states do not allow the exclusion or limitation of consequential or incidental damages, so the above exclusion may not apply to you.

HOW TO RECEIVE WARRANTY SERVICE

1. Contact the dealer from whom you purchased the appliance or any authorized Maycor servicer to receive warranty service under these warranties.
2. Should you not receive satisfactory warranty service from your local servicer, contact:

Customer Assistance
Maycor Appliance Parts and Service Company
240 Edwards Street, S.E.
Cleveland, TN 37311
(615) 472-3500

3. Have the following information available when requesting warranty service:
 - Your name and address.
 - The model and serial numbers of your appliance.
 - The name and address of your dealer or servicer.
 - The purchase date of your appliance.
 - A clear description of the problem.

The two warranties described above are the only written or expressed warranties given by Maycor. No one is authorized to increase, alter, or enlarge Maycor's responsibilities or obligations under these two warranties. These two warranties give you specific legal rights, and you may also have other rights which vary from state to state.