


# Use

# And

# Care



## Instructions for your Electric Wall Oven

### CONTENTS

<b>SAFETY INSTRUCTIONS</b> .....	1-3	How to bake or roast .....	8
<b>MECHANICAL CLOCK</b> .....	4	Common baking problems chart .....	8
Clock and timer .....	4	How to broil .....	9
Automatic oven cooking .....	4	<b>CONTINUOUS CLEANING OVEN</b> .....	10
Self clean oven .....	4	<b>SELF CLEANING OVEN</b> .....	11
<b>ELECTRONIC CLOCK</b> .....	5-6	<b>MAINTENANCE</b> .....	12
Clock .....	5	Light replacement .....	12
Timer .....	5	Oven door .....	12
Self clean oven .....	5	Circuit breaker (Canada only) .....	12
Automatic oven cooking .....	6	<b>CARE AND CLEANING CHART</b> .....	13
<b>USING YOUR OVEN</b> .....	7-10	<b>SERVICE</b> .....	14
Oven characteristics .....	7	Troubleshooting chart .....	14
Oven controls .....	7	How to obtain service .....	14
Oven indicator light .....	7	<b>WARRANTY</b> .....	15
Oven racks .....	7		
Preheating .....	7		
Double wall oven .....	7		

**INSTALLER** Please leave this manual with this appliance.

**CONSUMER** To save you time, energy and money, read and keep this manual for future reference.

The model and serial numbers of your appliance are found on the rating plate which is located on the front oven frame. Record and retain these numbers.

Model number: \_\_\_\_\_

Serial number: \_\_\_\_\_

Date of purchase: \_\_\_\_\_

# SAFETY INSTRUCTIONS

Information in the Safety Instruction section covers all electric cooking appliances. You may find some information that does not pertain to your particular appliance. Please review this section before using your cooking appliance.


The following instructions are based on safety considerations and must be strictly followed to eliminate the potential risks of fire, electric shock, or personal injury.

**PROPER INSTALLATION** – Be sure your appliance is properly installed and grounded by a qualified technician.



**NEVER USE YOUR APPLIANCE FOR WARMING OR HEATING THE ROOM.**

**STORAGE ABOVE RANGE** – To eliminate the hazard of reaching over hot surface elements, cabinet storage should not be provided directly above a unit. If provided, storage should be limited to infrequently used items that can be safely stored in an area subjected to heat. Temperatures may be unsafe for some items such as volatile liquids, cleaners, or aerosol sprays. If cabinet storage is provided, installation of a range hood that projects at least 5-inches beyond the bottom of the cabinet will reduce the hazards associated with such storage.



**WEAR PROPER APPAREL** –


Loose-fitting or hanging garments should never be worn while using the appliance.

**USER SERVICING** – Do not repair or replace any part of the appliance unless specifically recommended in the Use and Care Book. All other servicing should be referred to a qualified technician. Always disconnect unit or cut-off power to unit before any servicing.

**STORAGE IN, ON OR NEAR APPLIANCE** – Do not store or use gasoline or other flammable materials, vapors and liquids in the oven, near surface units or in the vicinity of this or any other appliance. The fumes can create a fire hazard or explosion. Do not use cooktop or oven as a storage area for food or cooking utensils.

**DO NOT USE WATER ON GREASE FIRES** –

Smother fire or flame or use dry chemical or foam-type extinguisher, if available or sprinkle heavily with baking soda.



**USE ONLY DRY POTHOLDERS** – Moist or damp potholders on hot surfaces may result in burns from steam. Do not let potholder touch hot heating elements. Do not use a towel or other bulky cloths.

**SURFACE COOKING UNITS:**

**USE PROPER PAN SIZE** – This appliance is equipped with one or more surface elements of different sizes. Select utensils having flat bottoms large enough to cover the surface element. The use of undersized utensils will expose a portion of the heating element to direct contact and may result in ignition of clothing. Proper relationship of utensil to element will also improve efficiency.

**NEVER LEAVE SURFACE UNITS UNATTENDED AT HIGH HEAT SETTINGS** –

Boilover causes smoking and greasy spillovers that may ignite.



**MAKE SURE DRIP BOWLS ARE IN PLACE** – Absence of these bowls during cooking may subject wiring or components underneath to damage.

**PROTECTIVE LINERS** – Do not use aluminum foil to line surface unit drip bowls or oven bottoms, except as suggested in the Use and Care Book. Improper installation of these liners may result in a risk of electric shock, or fire.

# SAFETY INSTRUCTIONS

**GLAZED COOKING UTENSILS** – Only certain types of glass, glass/ceramic, ceramic, earthenware, or other glazed utensils are suitable for range-top service without breaking due to the sudden change in temperature.



**UTENSIL HANDLES SHOULD BE TURNED INWARD AND NOT EXTEND OVER ADJACENT SURFACE UNITS** –

To reduce the risk of burns, ignition of flammable materials, and spillage due to unin-

tentional contact with the utensil, the handle of a utensil should be positioned so that it is turned inward, and does not extend over adjacent surface elements.

**DO NOT SOAK REMOVABLE HEATING ELEMENTS** – Heating elements should never be immersed in water. Immersing element in water would damage insulating material inside element.

## **OVENS:**

**USE CARE WHEN OPENING DOOR** – Let hot air or steam escape before removing or replacing food.

**DO NOT HEAT UNOPENED FOOD CONTAINERS** – Build-up of pressure may cause container to burst and result in injury.

**KEEP OVEN VENT DUCTS** (located under rear element; rear corner of cooktop; between oven door and control panel of wall oven or on backguard) **UNOBSTRUCTED**. Blockage of vent prevents proper oven air circulation and will affect oven performance. Avoid touching oven vent area while oven is on and for several minutes after oven is turned off. Some parts of the vent and surrounding area become hot enough to cause burns.

**PLACEMENT OF OVEN RACKS** – Always place oven racks in desired location while oven is cool. If rack must be moved while hot, use care to avoid contact of potholder with oven element.

## **VENTILATING HOODS:**

**CLEAN VENTILATING HOODS FREQUENTLY** – Grease should not be allowed to accumulate on hood or filter. When flaming foods under the hood, turn the fan off. The fan, if operating, may spread the flame.

## **IMPORTANT SAFETY NOTICE AND WARNING**

The California Safe Drinking Water and Toxic Enforcement Act of 1986 (Proposition 65) requires the Governor of California to publish a list of substances known to the State of California to cause cancer or reproductive harm, and requires businesses to warn customers of potential exposures to such substances.

Users of this appliance are hereby warned that when the appliance is engaged in the self-clean cycle there may be some low-level exposure to some of the listed substances, including carbon monoxide. Exposure to these substances can be minimized by properly venting the appliance to the outdoors during the self-clean cycle.

## **DEEP FAT FRYERS:**

Use extreme caution when moving the grease kettle or disposing of hot grease.

## **DO NOT TOUCH SURFACE ELEMENTS OR OVEN ELEMENTS, AREAS NEAR ELEMENTS OR INTERIOR SURFACES OF OVEN**

Elements may be hot even though they are dark in color. Areas near surface elements and interior surfaces of oven may become hot enough to cause burns. During and after use, do not touch or let clothing or other flammable materials contact heating elements, areas near elements or interior surfaces of oven until they have had sufficient time to cool. Among these areas are the cooktop, surfaces facing the cooktop, oven vent opening and surfaces near this opening, oven door, and oven window. Also, do not allow aluminum foil, meat probes or any other metal object, other than a utensil on a surface element, to contact heating elements.

## **ANTI-TIP BRACKET:**


**WARNING:** To reduce the risk of tipping of the appliance from unusual usage or by excessive loading of the oven door, the appliance must be secured by a properly installed anti-tip device. To check if device is installed properly: Use a flashlight and look underneath range to see that one of the rear leveling legs is engaged in the bracket slot. When removing appliance for cleaning, be sure anti-tip device is engaged when range is replaced. The anti-tip device secures the rear leveling leg to the floor, when properly engaged.

# SAFETY INSTRUCTIONS

## ADDITIONAL INFORMATION:

After appliance is installed, be certain all packing materials are removed from the appliance before operating the unit. If appliance is installed near a window, take steps to prevent curtains from blowing over surface elements creating a fire hazard.

Care should be given to location of appliance. Be sure floor covering under appliance, walls adjacent to appliance, cabinetry adjacent to appliance, and other materials adjacent to appliance can withstand prolonged heat. This is a heavy appliance and can settle into soft floor coverings such as cushioned vinyl. Use care when moving range on this type of floor covering.



## OVEN DOOR

Do not place excessive weight on an open oven door or stand on an open oven door as, in some cases, it could cause the range to tip over, breakage of the door or serious injury.

**CIRCUIT BREAKER OR FUSE** – Locate and mark breaker or fuse. Never replace a blown fuse or reset a breaker until you know what has caused the problem. Always replace a blown fuse with one of the correct amperage, do not use a substitute.

**CONTROL KNOBS** – Turn off control at the completion of a cooking operation.

## SELF CLEANING OVEN:

Do not clean door gasket. The door gasket is essential for a good seal. Care should be taken not to rub, damage, or move the gasket. Do not use oven cleaners or oven liner protective coating of any kind in or around any part of the self clean oven. Clean only parts listed in this booklet. Before self cleaning the oven, remove broiler pan, oven racks, and other utensils.

**CAUTION: DO NOT LEAVE FOOD OR COOKING UTENSILS, ETC., IN OVEN DURING THE SELF CLEANING MODE OF OPERATION.**

**ATTENTION: NE LAISSER AUCUN ALIMENT, USTENSILE DE CUISINE, ETC., DANS LE FOUR DURANT LE CYCLE D'AUTONETTOYAGE.**


On some models, a fan should be heard during the self clean cycle. If not, cancel clean cycle and call a serviceman before self cleaning again. (Refer to **CONTENTS** on front cover for location of self clean instructions and fan information.)

## SMOOTHTOP COOKTOP:

Do not cook on broken cooktop. If cooktop should break, cleaning solutions and spillovers may penetrate the broken cooktop and create a risk of electric shock. Contact a qualified technician immediately. Clean cooktop with caution. If a wet sponge or cloth is used to wipe spills on a hot cooking area, be careful to avoid steam burn. Some cleaners can produce noxious fumes if applied to a hot surface.

**DO NOT LEAVE CHILDREN ALONE** – Children should not be left alone or unattended in area where appliance is in use. They should never be allowed to sit or stand on any part of the appliance. **CAUTION:** Do not store items of interest to children in cabinets above an appliance or on the backguard of a range.

Children climbing on the appliance to reach items could be seriously injured. Children must be taught that the appliance and utensils in or on it can be hot. Children should be taught that an appliance is not a toy. They should not be allowed to play with controls or other parts of the unit.




## IN CASE OF FIRE:

1. Turn off appliance and ventilating hood.
2. Use dry or foam-type extinguisher or baking soda to smother flame. Never use water on a grease fire.
3. If fire is in oven, smother by closing oven door.
4. If fire is in a pan on the surface unit, cover pan.

**– SAVE THESE INSTRUCTIONS –**

# MECHANICAL CLOCK

## CLOCK AND TIMER



**TO SET CLOCK:** Push in and turn Minute Minder knob to the left to the correct time-of-day. Be sure Minute Minder hand is on OFF after setting clock.


**TO SET MINUTE MINDER:** Turn knob to either direction to the desired time. When the bell rings, manually turn the Minder to OFF.

## AUTOMATIC OVEN COOKING

Automatic cooking feature is used to turn the oven on and off at a preset time-of-day. This feature can be used to delay the start of a cooking operation or a self clean cycle, if equipped.

**IMPORTANT:** Highly perishable foods such as dairy products, pork, poultry, seafoods, or stuffing are not recommended for delayed cooking. If cooking more than one food, select foods that cook for the same length of time and at the same oven temperature.

The automatic cooking feature will not operate unless the clock is functioning and is set at the correct time-of-day.



1. Place food in the oven.
2. Push in and turn START knob to the time-of-day you wish cooking to begin. If you wish to begin cooking immediately, do NOT set the START knob.
3. To delay START of cooking: Push in and turn STOP knob to the time-of-day you wish the oven to turn off.
4. Turn oven thermostat knob to the desired setting. Turn selector knob to TIME BAKE.


The oven will automatically turn on and off at the preset times. Remove food, turn the thermostat knob to OFF if knob has OFF setting. Turn selector knob to OFF.

## SELF CLEAN OVEN


See page 11 for additional information.

### TO OPERATE SELF CLEAN

1. Close door and move door lock lever to the right until it rests in the lock position.



2. Turn thermostat and selector knobs to CLEAN.
3. Set cleaning time for up to 3 hours. Push in and turn STOP knob ahead 3 hours. Be sure START knob is in the OUT position.




### TO CANCEL CLEAN CYCLE:

Turn STOP knob until knob pops out. Turn thermostat and selector knobs to OFF. If the LOCK light has not turned on, the lock lever can be moved to the left and the oven door can be opened. If the LOCK light has turned on, allow oven to cool up to 1 hour. Once LOCK light turns off, oven door can be unlocked and opened. Door and latch will be damaged if the latch is forced to the left before the lock light turns off.

### TO DELAY CLEAN CYCLE:


1. Turn STOP knob to the time-of-day you wish the oven to turn off.
2. Turn START knob to the time-of-day you wish the clean cycle to begin. Remember, the maximum clean cycle is 3 hours.
3. Close and lock door.
4. Turn thermostat and selector knobs to CLEAN.

# ELECTRONIC CLOCK



## CLOCK

**To set clock:** Press and hold TIMER and BAKE TIME buttons then turn SET knob in either direction to set time-of-day.




When power is first supplied to the oven or if there is a power failure the display will blink 88:88. Follow the instructions above to set the clock.

## TIMER

**To set timer:** Press TIMER button. Turn SET knob to set desired time.

Display will immediately begin counting down in seconds. Timer can be set for up to 99 minutes.



When time lapses, the alarm will sound and the current time-of-day will reappear in the display. Press TIMER button to stop alarm.


**To cancel:** Press TIMER button and turn SET knob until display reads all zeros.

## SELF CLEAN OVEN

See page 11 for additional information.

### TO SET CLEAN CYCLE:

1. Close door and move door lock lever to the right until it rests in the lock position.



2. Turn thermostat and selector knobs to CLEAN.
3. Press SELF CLEAN button. 3:00 will appear in the display.

When the SELF CLEAN button is pressed, the oven will automatically clean for 3 hours. A shorter (2 hours) or long (up to 4 hours) clean cycle can be selected by turning the SET knob after pressing the SELF CLEAN button.

To prevent accidentally changing the clean cycle, press TIMER button to return display to time-of-day.

### TO DELAY CLEAN CYCLE:

1. Close and lock door.
2. Turn thermostat and selector knobs to CLEAN.
3. Press SELF CLEAN button.
4. Press STOP TIME button. Turn SET knob to time-of-day you wish the clean cycle to end.


### TO CANCEL CLEAN CYCLE:

Press SELF CLEAN button. Turn thermostat and selector knobs to OFF. If the LOCK light has not turned on, the lock lever can be moved to the left and the oven door can be opened. If the LOCK light has turned on, allow oven to cool, up to 1 hour. Once LOCK light turns off, oven door can be unlocked and opened. Door and lever will be damaged if the lever is forced to the left before the lock light turns off.

## IMPORTANT

ON SELF CLEAN MODELS, DO NOT MOVE OVEN DOOR LOCK LEVER TO THE RIGHT DURING BROILING OR BAKING. Oven door will lock, elements will turn off, and the door will stay locked until oven cools. Turn oven off if lock lever is accidentally moved to CLEAN then reset oven.

# ELECTRONIC CLOCK



## AUTOMATIC OVEN COOKING

Automatic cooking feature is used to turn the oven on and off at a preset time-of-day. This feature can be used to delay the start of a cooking operation or a self clean cycle, if equipped.

The automatic cooking feature will not operate unless the clock is functioning and is set at the correct time-of-day.

**IMPORTANT:** Highly perishable foods such as dairy products, pork, poultry, seafoods, or stuffing are not recommended for delayed cooking. If cooking more than one food, select foods that cook for the same length of time and at the same oven temperature.

### TO BAKE BY TIME – with immediate start.

1. Press BAKE TIME button. 0:00 appears in the display for 3 seconds.
2. Turn SET knob to desired cooking time. Display is in hours and minutes. Example: 1:30 is 1 hour, 30 minutes.
3. Turn selector knob to TIMED BAKE and the thermostat knob to the desired temperature. The oven automatically turns on and the display begins to count down.

An alarm sounds at the end of cooking and the oven automatically turns off. To turn alarm off, press any button. At the end of cooking, turn the oven thermostat and selector knobs to OFF.

### TO BAKE BY TIME – with delayed start.

1. Press BAKE TIME button.
2. Turn SET knob to desired cooking time.
3. Press STOP TIME button.
4. Turn SET knob to desired time-of-day you wish the oven to turn off.
5. Turn selector knob to TIMED BAKE and the thermostat knob to the desired temperature. The oven automatically turns on and off at the preset times.

An alarm sounds at the end of cooking and the time-of-day reappears in the display. Turn the oven thermostat and selector knobs to OFF.

### ADDITIONAL INFORMATION

To cancel a program: Press BAKE TIME button then turn SET knob until display reads 0:00. The current time-of-day will reappear in the display. Turn oven thermostat and selector knobs to OFF.

To check a program: Press BAKE TIME to see how long food has to cook. Press STOP TIME to see what time the oven will turn off.

To prevent accidentally changing the program: Press TIMER and BAKE TIME buttons. ▼ indicator will flash above BAKE TIME and STOP TIME to show that the oven is programmed for an automatic cooking operation. Time-of-day will reappear in the display.

### EXAMPLE

Food is to cook for one hour and 30 minutes at 350°F.

1. Press BAKE TIME button.
2. Turn SET knob until 1:30 (1 hour, 30 minutes) appears in the display.
3. Turn selector to TIMED BAKE and thermostat to 350°F.

### EXAMPLE

Food is to cook for 2 hours and 30 minutes at 350°F. You wish the food to be cooked by 6:00.

1. Press BAKE TIME button.
2. Turn SET knob until 2:30 (2 hours, 30 minutes) appears in the display.
3. Press STOP TIME pad.
4. Turn SET knob until 6:00 appears in the display.
5. Turn selector to TIMED BAKE and thermostat to 350°F.


The oven will turn on at 3:30, cook the food for 2 1/2 hours and will automatically turn off at 6:00.

# USING YOUR OVEN

## OVEN CHARACTERISTICS

Every oven has its own characteristics. You may find that the cooking times and temperatures you were accustomed to with your previous oven may need to be altered slightly with your new oven. Please expect some differences with this new oven.

## OVEN CONTROLS



The THERMOSTAT knob is used to select and maintain the oven temperature. Always turn this knob just TO the desired temperature not to a higher temperature and then back. Turn this knob to OFF if knob has an OFF setting, whenever the oven is not in use.

The SELECTOR knob determines the type of oven operation. Turn this knob to desired setting. Each setting is identified by an indent (stop) and a "click" sound.

To turn the oven on, **both** the Thermostat and Selector knobs must be set. The oven will not operate if the Selector knob is left in the OFF position. To turn the oven off, turn both knobs to the OFF position, if thermostat has an OFF setting.

## OVEN INDICATOR LIGHT

The OVEN indicator light, located on the control panel, turns on whenever the oven is turned on. When the oven reaches the preset temperature, the indicator light turns off and then cycles on

and off as the oven elements cycle on and off.

## OVEN RACKS

The two oven racks are designed with a "lock-stop" position to keep racks from accidentally coming completely out of the oven.

**To remove:** Be sure rack is cool. Pull rack out to the "lock-stop" position. Tilt up and continue pulling until rack releases.

**To replace:** Place rack on rack supports, tilt up and push toward rear of oven. Pull rack out to "lock-stop" position to be sure rack is correctly replaced.


### RACK POSITIONS:

**RACK 1** (top of oven) used for broiling thin foods.

**RACK 2** used for one-rack baking or broiling thicker cuts of meat.

**RACK 3** used for most one-rack baking and for roasting some meats.

**RACK 4** used for roasting large meats, cooking larger foods and for baking angel food cake or pie shells.



### HINTS:

If cooking on two racks, stagger pans so one is not directly over the other. Use rack positions 1 and 3, 2 and 4, or 1 and 4, depending on results, when cooking on two racks.

For optimum baking results of cakes, cookies or biscuits, use one rack. Position rack so food is in the center of the oven. Allow 2 inches between edge of utensil and the oven sides or adjacent utensils.

NEVER place pans directly on the oven bottom.

Do not cover entire rack with aluminum foil or place foil directly under utensil. To catch spillovers, cut a piece of foil a little larger than the pan and place it on the rack below the rack containing the utensil.

## IMPORTANT

ON SELF CLEAN MODELS DO NOT MOVE OVEN DOOR LOCK LEVER TO THE RIGHT DURING BROILING OR BAKING. Oven door will lock, elements will turn off, and the door will stay locked until oven cools. Turn oven off if lock lever is accidentally moved to CLEAN then reset oven.

## PREHEATING

Preheating is necessary for baking. Allow oven to heat for 10 to 15 minutes before adding food. Preheat broil element for 5 to 10 minutes if darker browning is desired or if broiling thin (3/4-inch) meats. It is not necessary to preheat oven for roasting.

Selecting temperature higher than desired will NOT preheat the oven any faster. Preheating at a higher temperature may have a negative effect on baking results.

## DOUBLE WALL OVEN

The lower oven is equipped with only a bake element. For best results, use the upper oven for delicate cooking such as cakes, cookies, biscuits, or pies. Use either oven for non-critical type of cooking such as meats or casseroles.



# USING YOUR OVEN

## HOW TO BAKE OR ROAST

1. When cool, position rack in oven depending on what you are baking.
2. **To set oven:** Turn thermostat knob to desired temperature and the selector

3. Place food in center of oven, allowing a minimum of 2 inches between utensil and oven walls.
4. Check food for doneness at minimum time in recipe. Cook longer if neces-

sary. Remove food from the oven and turn oven thermostat and selector to OFF.

If you have carefully followed the basic instructions and still experience poor results, these suggestions may be helpful:

## COMMON BAKING PROBLEMS AND WHY THEY HAPPEN

PROBLEM	CAUSE	PROBLEM	CAUSE
<i>Cakes are uneven.</i>	Pans touching each other or oven walls. Batter uneven in pans. Temperature set too low or baking time too short. Oven not level. Undermixing. Too much liquid.	<i>Cakes don't brown on top.</i>	Incorrect rack position. Temperature set too low. Overmixing. Too much liquid. Pan size too large or too little batter in pan. Oven door opened too often.
<i>Cake high in middle.</i>	Temperature set too high. Baking time too long. Overmixing. Too much flour. Pans touching each other or oven walls. Incorrect rack position.	<i>Excessive shrinkage.</i>	Too little leavening. Overmixing. Pan too large. Temperature set too high. Baking time too long. Pans too close to each other or oven walls.
<i>Cake falls.</i>	Too much shortening or sugar. Too much or too little liquid. Temperature set too low. Old or too little baking powder. Pan too small. Oven door opened frequently. Added incorrect type of oil to cake mix. Added additional ingredients to cake mix or recipe.	<i>Uneven texture.</i>	Too much liquid. Undermixing. Temperature set too low. Baking time too short.
<i>Cakes, cookies, biscuits don't brown evenly.</i>	Incorrect rack position. Oven door not closed properly. Door gasket not sealing properly. Incorrect use of aluminum foil. Oven not preheated. Pans darkened, dented or warped.	<i>Cakes have tunnels.</i>	Not enough shortening. Too much baking powder. Overmixing or at too high a speed. Temperature set too high.
<div style="border: 1px solid black; padding: 5px;">                     For optimum results, bake on one rack. If baking cakes on two racks, place pans toward front of oven on upper rack and pans toward back of oven on lower rack.                 </div>		<i>Cakes crack on top.</i>	Batter overmixed. Temperature set too high. Too much leavening. Incorrect rack position.
		<i>Cake not done in middle.</i>	Temperature set too high. Pan too small. Baking time too short.
		<div style="border: 1px solid black; padding: 5px;">                     If additional ingredients were added to mix or recipe, expect cooking time to increase.                 </div>	
<i>Cakes, cookies, biscuits too brown on bottom.</i>	Oven not preheated. Pans touching each other or oven walls. Incorrect rack position. Incorrect use of aluminum foil. Placed 2 cookie sheets on one rack. Used glass, darkened, stained, warped or dull finish metal pans. (Use a shiny cookie sheet.)	<i>Pie crust edges too brown.</i>	Temperature set too high. Pans touching each other or oven walls. Edges of crust too thin.
<div style="border: 1px solid black; padding: 5px;">                     Follow utensil manufacturer's instructions for oven temperature. Glassware and dark utensils such as Ecko's Baker's Secret require lowering the oven temperature by 25° F.                 </div>		<i>Pies don't brown on bottom.</i>	Used shiny metal pans. Temperature set too low.
		<i>Pies have soaked crust.</i>	Temperature too low at start of baking. Filling too juicy. Used shiny metal pans.

# USING YOUR OVEN

## HOW TO BROIL

Broiling is a method of cooking tender meats by direct heat under the element. The cooking time is determined by the distance between the meat and the element, the desired degree of doneness and the thickness of the meat.

Broiling requires the use of the broiler pan and insert. The correct position of the insert in the pan is very important. The broiler insert should be placed in the pan so grease will drain freely. Improper use may cause grease fires.


The broiler insert CANNOT be covered with aluminum foil as this prevents fat from draining into pan below. However, for easier cleaning, the broiler pan can be lined with foil. Do not use disposable

broiler pans. They do not provide a separate tray.

Preheat broil element 5 to 10 minutes if darker browning is desired.

### TO BROIL:

1. Prepare meat by removing excess fat and slashing remaining fat, being careful not to cut into meat. This will help keep meat from curling.
2. Place broiler pan on the recommended rack position. For brown exterior and rare interior, the meat should be close to the element. Place further down if you wish meat well done.
3. To set oven: Turn both the thermostat and selector knobs to BROIL.
4. Broiling should be done with oven door opened to the broil "STOP" position (opened about 4 inches.).



5. Follow suggested times on broiling chart. Meat should be turned once about half way through cooking.
6. Check doneness by cutting a slit in meat near center for desired color.
7. Turn both the oven thermostat and selector to OFF after cooking. Broil times may need to be increased if oven is installed on a 208-volt circuit.

## BROILING CHART

TYPE OF FOOD	RACK #	DONENESS	TOTAL TIME
STEAKS 1-inch	2	rare medium well	12 to 14 min. 16 to 18 min. 19 to 21 min.
1 1/2-inch	2	rare medium well	18 to 20 min. 22 to 24 min. 25 to 30 min.
HAMBURGER 3/4 to 1-inch	2	rare medium well	10 to 12 min. 12 to 15 min. 15 to 18 min.
CHICKEN HALVES	2	well done 185°F	30 to 40 min.
FISH FILLETS Fresh Frozen	2 2	flaky flaky	10 to 15 min. 15 to 20 min.
HAM SLICE (boneless) 1/2-inch Pre Cooked Uncooked	2 2	well done	8 to 15 min. 15 to 20 min.
BACON	1	well done	6 to 8 min.
PORK CHOPS 3/4-inch	2	well done	14 to 16 min.

# CONTINUOUS CLEANING OVEN (if equipped)

## WHAT IS THE CONTINUOUS CLEANING OVEN?

The finish of the Continuous Cleaning Oven is identified by its dark gray color, white stipple and rough, porous texture. The rough texture prevents grease spatters from forming beads which run down the walls leaving unsightly streaks. Rather, the rough texture absorbs spatters and allows them to spread, thus exposing a larger area to the hot oven air. The catalyst, when exposed to heat, speeds the oxidation of soil.

Cleaning action automatically begins whenever the oven is turned on for baking or roasting. The oven **MUST** be on for cleaning to take place. No cleaning will occur when the oven is off. The special catalytic finish must be exposed to hot oven air before soil will begin to gradually reduce in size.

## FACTORS AFFECTING LENGTH OF CLEANING TIME

The higher the oven temperature, the faster the cleaning action. The length of cleaning time will depend on these factors: Type of soil, amount or size of soil, oven temperature and length of time oven is in use. Time may vary from a few minutes to several hours. Soil deposited at the end of a cycle may still be visible. This will usually fade with continued oven use until the soil gradually disappears or can be wiped up manually. The oven will appear presentably clean, even though some spatters may be present.

## MANUALLY CLEANING HEAVY SPILLOVERS

The special finish will clean most spatters during normal oven use unless there is a heavy buildup of soil. Heavy spillovers such as pie or casserole boilovers will not clean effectively without some manual help. The crusty or varnish-like stains that form from these spillovers clog the pores and prevent the special finish from being exposed to the hot oven air. This greatly reduces the cleaning effectiveness of the finish.

These crusty or varnish-like stains must either be removed or broken up before cleaning can effectively take place.

## TO MANUALLY CLEAN HEAVY SPILLOVERS

Brush off heavy soil with a nylon brush or plastic pad. **DO NOT USE** paper towels, cloths or sponges for the oven walls are porous and particles of these materials will rub off on the walls. Rinse area with clear water only.



## HINTS

Brittle crusts or stains can be loosened by **GENTLY** tapping stain with a wooden or plastic utensil. Brush away any loose soil that flakes off. Varnish type stains usually need to be softened with a small amount of water or damp cloth. Remaining soil will gradually reduce with continued oven use at normal baking temperatures.

**DO NOT USE ANY TYPE OF OVEN CLEANER, POWDERED CLEANSERS, SOAP, DETERGENT OR PASTE ON ANY CONTINUOUS CLEANING SURFACE, ALSO, DO NOT USE ANY ABRASIVE MATERIALS, STEEL WOOL, SHARP INSTRUMENTS OR SCRAPERS FOR THEY WILL DAMAGE THE FINISH.**

Avoid spillovers by using utensils that are large enough to hold food. A cookie sheet or piece of aluminum foil, just a little larger than the pan, can be placed on the rack directly below the rack holding the utensil to catch spills.

Over a period of time, wear marks may appear on the embossed rack supports. This is normal and results from sliding the racks in and out of the oven. Wear marks will not affect the cleaning action of the oven.

# SELF CLEAN OVEN (if equipped)

The self clean oven uses temperatures above normal cooking temperatures to automatically clean the entire oven.

See page 4 for instructions on how to set the clean cycle on oven equipped with a mechanical clock. See page 5 for instructions on how to set the clean cycle on oven equipped with an electronic clock.

The self clean oven uses temperatures above normal cooking temperatures to automatically clean the entire oven.

## BEFORE SELF CLEANING

Remove all pans from the oven. Racks may be left in, but will discolor and may not slide easily after cleaning.

Clean oven frame, door frame and around the oven vent with a non-abrasive cleaning agent such as Bon Ami. These areas are not exposed to cleaning temperatures and should be cleaned to prevent soil from baking on during the clean cycle.

Wipe up excess grease or spillovers from the oven bottom to prevent excessive smoking during the clean cycle.

**DO NOT USE OVEN CLEANERS OR OVEN LINER PROTECTIVE COATINGS OF ANY KIND ON THE SELF CLEAN OVEN FINISH OR AROUND ANY PART OF THE OVEN.**

To prevent damage, do not clean or rub the gasket around the front oven frame. The gasket is designed to seal in heat during the clean cycle.

## DURING SELF CLEANING

The oven automatically begins to heat when the door is locked. As the oven reaches cleaning temperatures, the LOCK light will turn on. At this point, the oven door can not be manually opened. Do not force latch to the left once the lock light turns on.

The first few times the oven is cleaned, some smoke and odor may be detected. This is normal and will reduce or disappear with use. If the oven is heavily soiled, or if the broiler pan is left in the oven, smoke and odor may occur.

As the oven heats and cools, you may hear sounds of metal parts expanding and contracting. This is normal and will not damage your appliance.

## AFTER SELF CLEANING

About one hour after the clean cycle is completed, the internal lock will disengage, LOCK light will turn off and the door latch can be returned to its original (unlocked) position. **Do not attempt to unlock door until lock light has turned off. Door and latch will be damaged if the latch is forced to the left before the lock light turns off.**

Some soil may leave a light gray, powdery ash which can be removed with a damp cloth. If soil remains, it indicates that the clean cycle was not long enough. The soil will be removed during the next clean cycle.

If the oven racks do not slide smoothly after a clean cycle, wipe racks and embossed rack supports with a small amount of vegetable oil to restore ease of movement.

Fine, hair-like lines may appear in the oven interior or oven door. This is a normal condition resulting from heating and cooling of the porcelain finish. These lines do not affect the performance of the oven.


# MAINTENANCE

## LIGHT REPLACEMENT

Before replacing light bulb, DISCONNECT POWER TO OVEN. Be sure bulb is cool. Do not touch a hot bulb with a damp cloth as the bulb may break.


## NON SELF CLEAN OVEN MODEL

**To replace oven light:** Remove oven racks. Oven bulb is protected with a metal perforated screen. Use a Phillips-head screwdriver to remove two screws securing screen to back of oven. Use care not to damage capillary tube near screen.



## SELF CLEAN OVEN MODELS

**To replace oven light:** Remove 4 screws and plates as illustrated below. Use care when removing gasket, it may tear.



**Very carefully** remove bulb with a dry potholder to prevent possible harm to hands. Replace with a 40 watt appliance bulb. Reconnect power to oven and reset clock.

## OVEN DOOR

When opening oven door, allow steam and hot air to escape before reaching into oven to check, add or remove food.


### CAUTION:

Hinge arms are spring mounted and will slam shut against the oven if accidentally hit. **Never place hand or fingers between the hinges and the front oven frame.** You could be injured if hinge snaps back.

Do not attempt to open or close door until door is completely seated on hinge arms. Never turn on oven unless door is properly in place. When baking, be sure door is completely closed. Baking results will be affected if door is not securely closed.

### DESIGN 1

**To remove lift-off door:** Open door to the "stop" position (opened about 4 inches) and grasp door with both hands at each side. Do not use door handle to lift door. Lift up evenly until door clears the hinge arms.



**To replace door:** Grasp door at each side, align slots in the door with the hinge arms and slide door down onto the hinge arms until completely seated on hinges.


### DESIGN 2

On some models, the oven door is equipped with a special hinge that locks into place as the door is removed.

#### To remove door:

1. Open door to the broil stop position (open about 4-inches.)
2. Grasp the sides of the door at the middle of the door. **Slowly** lift door straight up.

3. As you lift the door up, **very slightly** open door by pulling door toward you. Check to be sure latches swing down into the notches on the hinge arms.




#### To replace door:

1. Grasp sides of door and align slots in door with hinge arms.
2. **Very slightly** pull door to a more open position as you slide the door down onto the hinge arms. The sliding action of the door will disengage the latches on the hinge arms.
3. Gently push the door downward until the door rests evenly on the hinges. Close door.

## CIRCUIT BREAKER

### CANADIAN APPLIANCE ONLY

Your appliance is equipped with a circuit breaker box. The box is located either on a wall or in a cabinet next to or near the appliance. If part or all of the appliance does not operate, check to see if one of the breakers has tripped. Reset the breaker to the ON position.



# CARE AND CLEANING

PARTS	CLEANING AGENTS	DIRECTIONS Be sure all parts are cool before cleaning. Be sure all parts are properly replaced after cleaning.
<b>Broiler pan &amp; insert</b>	Soap & water. Plastic scouring pad. Soap filled scouring pad.	Remove from oven after use. Cool then pour off grease. Place soapy cloth over insert and pan; let soak to loosen soil. Wash in warm soapy water. Use soap filled scouring pad to remove stubborn soil. Clean in dishwasher if desired.
<b>Baked Enamel: Oven door</b>	Soap & water. Paste of baking soda & water.	Use a dry paper towel or cloth to wipe up spills, especially acid spills, as soon as they occur. (This is especially important for white surfaces.) When surface is cool, wash with soap and water. Do not use abrasive or harsh cleaning liquids and powders or oven cleaners. These will scratch and permanently damage the finish. Dry with a soft cloth.
<b>Control knobs</b>	Mild detergent & water.	To remove knobs, gently pull forward. Wash in mild detergent and water. Do not use abrasive cleaning agents. They will scratch finish and remove markings. Rinse, dry and replace. Turn each knob ON to see if knobs have been replaced correctly.
<b>Glass: Control panel</b>	Soap & water. Paste of baking soda & water. Window cleaning fluid or ammonia.	Wash with soap and water. Remove stubborn soil with paste of baking soda and water. Do not use abrasive materials such as scouring pads, steel wool or powdered cleaning agents. They will damage glass. Rinse with clear water and dry. To prevent staining of oven window, never use excessive amounts of water which may seep under or behind glass.
<b>Metal finishes: Trim parts</b>	Soap & water. Paste of baking soda & water.	Wash with soap and water. Remove stubborn soil with paste of baking soda and water. Do not use oven cleaner, abrasive or caustic agents. They will damage the finish.
<b>Oven Elements</b>		Elements are self cleaning. Soil will burn off as elements are used. Do not spray oven cleaner on elements, electrical hook up or connection.
<b>Oven racks</b>	Soap & water. Cleansing powders & plastic pads. Soap filled scouring pad.	Clean with soapy water. Remove stubborn soil with cleansing powder or soap filled scouring pad. Rinse and dry.
<b>Plastic finishes: Door handle</b>	Soap & water.	Never use oven cleaner, abrasive or caustic cleaning agents on vinyl finishes.
<b>Porcelain enamel: Oven</b> See page 10 for continuous clean oven.  See pages 4, 5 and 12 for self clean oven.	Mild liquid cleaners, detergent or soap & water. Cleansing powders and non abrasive nylon or plastic pads.	Porcelain enamel is glass fused on metal. It may crack or chip with misuse. Clean with soap and water when parts are cool. All spillovers, especially acid or sugar spillovers, should be wiped up immediately with a dry cloth. Surface may discolor or dull if soil is not removed. When surface is cool, clean with warm soapy water. NEVER WIPE OFF A WARM OR HOT ENAMEL SURFACE WITH A DAMP CLOTH. THIS MAY CAUSE CRACKING AND CHIPPING. Never use abrasive or caustic cleaning agents on exterior finish of oven. Use commercial oven cleaner on porcelain – lined oven <b>ONLY</b> . Carefully read and follow manufacturer's instructions.
<b>Silicone rubber door gaskets</b>	Soap & water.	Wash with soap. Rinse thoroughly. <b>DO NOT REMOVE.</b>

# SERVICE

<b>PART OR ALL OF YOUR OVEN DOES NOT OPERATE</b>	Is the oven plug disconnected from the electrical outlet? • Are house fuses blown or circuit breakers tripped? • Is the oven plug loose or improperly plugged in? Has power supply to your home been interrupted? • Was oven properly set? See page 4 or 5.
<b>ELEMENTS FAIL TO TURN ON OR HEAT FOOD PROPERLY</b>	Is oven plug disconnected from the electrical outlet? • Check circuit breaker or fuse box for tripped circuit breakers or blown fuses. • Is element properly plugged into receptacle? • Was incorrect utensil used? (NOTE: Expect cooking times to increase if range is connected to 208 volts). • Have serviceman check element.
<b>FOOD NOT BAKING SATISFACTORILY</b>	Are racks properly in place and in correct position for what you are baking? • Is oven level? • Are you using the proper pan? • Is it bright, not soiled or dark colored? • Have you used foil incorrectly? • Are you using standard measuring utensils? • Did you preheat if recommended? • Oven temperature is incorrectly set – too low or too high. See common baking complaint chart on page 8.
<b>OVEN DOES NOT OPERATE</b>	Was electronic or mechanical clock set properly? See page 4 or 5. Is the oven disconnected from the electrical power? • Was the Selector knob turned to bake or broil? • Was oven properly set?
<b>OVEN LIGHT DOES NOT WORK</b>	Is bulb loose or burned out?

## SERVICE

Do not attempt to service the appliance yourself unless directed to do so in this book. Contact the dealer who sold you the appliance for service.

## HOW TO OBTAIN SERVICE

When your appliance requires service or replacement parts, contact your Dealer or Authorized Servicer. Use only genuine factory or Maycor parts if replacement parts are necessary. Consult the Yellow Pages in your telephone directory under appliance for the service center nearest you. Be sure to include your name, address, and phone number, along with the model and serial numbers of the appliance. (See front

cover for location of your model and serial numbers.)

If you are unable to obtain service, write to us. Our address is found on the rating plate. See front cover for location of rating plate.

If you are not satisfied with the local response to your service requirements, call or write MAYCOR Appliance Parts and Service Company, 240 Edwards Street, S.E., Cleveland, TN 37311, (615) 472-3500. Include or have available the complete model and serial numbers of the appliance, the name and address of the dealer from whom you purchased the appliance, the date of purchase and details concerning your problem.

If you did not receive satisfactory service through your servicer or Maycor you may contact the Major Appliance Consumer Action Panel by letter including your name, address, and telephone number, as well as the model and serial numbers of the appliance.

Major Appliance Consumer Action Panel  
20 North Wacker Drive  
Chicago, IL 60606

MACAP (Major Appliance Consumer Action Panel) is an independent agency sponsored by three trade associations as a court of appeals on consumer complaints which have not been resolved satisfactorily within a reasonable period of time.

# FULL ONE-YEAR WARRANTY

## DOMESTIC GAS OR ELECTRIC RANGE

Maycor Appliance Parts & Service Company will repair or replace, without charge, any part of your product which has a defect in material or workmanship during the first year after the date of the original installation. This warranty extends to any owner during the one-year warranty period.

## LIMITED 5 YEAR WARRANTY

On electric ranges equipped with solid disc or smoothtop heating elements, and on gas ranges with sealed burners, for an additional 4 year period beyond the first year of the general coverage of this warranty, Maycor will replace any of the solid disc or smoothtop heating elements, or sealed burners which fail to heat as a result of defective workmanship or material. Additionally, Maycor will replace any smoothtop cooking surface which cracks or breaks during normal household cooking. These parts must be installed by a qualified person. Any labor charge required for replacement is not covered by this warranty.

### HOW TO OBTAIN SERVICE

To obtain the repair or replacement of a defective part under these warranties, you should contact the dealer from whom you purchased the appliance or a servicer he designates.

### WHAT IS NOT COVERED BY THESE WARRANTIES

1. Conditions and damage resulting from improper installation, delivery, unauthorized repair, modification, or damage not attributable to a defect in material or workmanship.
2. Conditions resulting from damage, such as: (1) improper maintenance, (b) misuse, abuse, accident, or (c) incorrect electrical current or voltage.
3. Warranties are void if the original serial number has been removed, altered, or cannot be readily determined.
4. Light bulbs.
5. Any product used for other than normal household use. It does not extend to products purchased for commercial or industrial use.
6. Any expense incurred for service calls to correct installation errors or to instruct you on how to use the products.
7. CONSEQUENTIAL OR INCIDENTAL DAMAGES SUSTAINED BY ANY PERSON AS A RESULT OF ANY BREACH OF THESE WARRANTIES OR ANY IMPLIED WARRANTY. Some states do not allow the exclusion or limitation of consequential or incidental damages, so the above exclusion may not apply to you.

### ADDITIONAL HELP

If you are not satisfied with the local response to your service requirements and wish to contact Maycor, please address your letter to the Customer Relations Department, Maycor Parts & Service Company, 240 Edwards Street, S.E., Cleveland, TN 37311 or call (615) 472-3500. To save time, your letter should include the complete model and serial numbers of the warranted appliance, the name and address of the dealer from whom you purchased the appliance, the date of purchase and details concerning your problem.

These warranties are the only written or expressed warranties given by Maycor. No one is authorized to increase, alter, or enlarge Maycor's responsibilities or obligations under these warranties. These warranties give you specific legal rights, and you may also have other rights which vary from state to state.

8109P059-60  
(6/91)