

USE AND CARE FOR THE CANNING ELEMENT ACCESSORY KIT

(Model Number CE-1)

SAFETY PRECAUTIONS

Refer to the Use and Care Booklet that came with your appliance for complete safety information and additional operating instructions.

Read these instructions before using the canning element

- The canning element is intended for use on specific appliance models. To determine if the canning element can be used with your appliance, check to see if the following manufacturing number is listed on your appliance's data rating plate: MFG # E25378. See the Use and Care Booklet that came with your appliance for location of the rating plate.
- **DO NOT TOUCH SURFACE ELEMENTS OR AREAS NEAR ELEMENTS.** Surface elements may be hot even though they are dark in color. Areas near surface elements may become hot enough to cause burns. During and after use, do not touch, or let clothing or other flammable materials contact surface elements or areas near elements until they have had sufficient time to cool. The cooktop is included among these areas.
- Make sure the drip bowl is in place. Absence of this bowl during cooking may subject wiring or components underneath to damage. Do not use protective liners or aluminum foil to line the drip bowl except as suggested in the Use and Care Booklet that came with your appliance. Improper installation of these liners may result in a risk of electric shock or fire.

ABOUT THE CANNING ELEMENT ACCESSORY

The Canning Element Optional Accessory Kit makes it possible to use larger cookware or canners on cooktops featuring coil-type surface elements. The kit includes a canning element and a chrome drip bowl.

The use of large or oversized cookware on a conventional coil element is not recommended. If larger cookware is used on a conventional coil element, heat can build-up between the pan and the cooktop and may result in damage to the cooktop, surface element, drip bowl, and pan.


The "elevated" design of the canning element helps to eliminate this problem. The taller canning element raises the pan above the cooktop thus allowing more air to circulate underneath to help keep surface temperature cooler.

HOW TO INSTALL THE CANNING ELEMENT AND DRIP BOWL

Before installing the canning element and drip bowl, be sure all control knobs are in the OFF position and be sure all parts are cool before handling.

1. Raise the large surface element up and carefully pull it out and away from the receptacle.
2. Remove the drip bowl and replace it with the drip bowl that came in the optional accessory kit. (NOTE: Because of the higher heat associated with larger cookware or canning, it is normal for the drip bowl to discolor over time.)

3. Insert the terminals of the canning element into the receptacle on the cooktop. Gently lift up on the outer edge of the element while inserting the terminals into the receptacle. Gently press down on the outer edge of canning element until the element sits level on the drip bowl.



4. After use, turn control knob to the OFF position. Be sure all control knobs are off before removing the canning element. When cool, remove the canning element and drip bowl. Replace with the element and drip bowl that came with your cooking appliance.

COOKING AND CANNING TIPS

- When using larger cookware or canners, be sure the pan is centered and balanced on the canning element. Flat-bottomed cookware provide the best results. The cookware should NOT be so large that it touches the cooktop, rests on two elements or on the edge of the cooktop.
- Use the HIGH setting to begin the cooking operation or bring water to a boil. Then, reduce to a heat setting that will maintain the boil or desired cooking action. Covering the pan will help reduce the bring-to-boil time. A lower heat setting can be used if the pan is covered.
- **CANNING:** Use canning recipes from a reliable source such as the canner manufacturer, manufacturers of canning jars, the USDA Extension Service or your local county extension agent.

Use the High setting just until the water comes to a boil or pressure is reached in the pressure canner, then reduce to a heat setting that will maintain the boil or pressure.

Canning creates large amounts of steam. Use care and follow equipment instructions to avoid burns from steam, hot liquids or hot cookware.

CANNING ELEMENT WARRANTY (FIVE YEAR PART REPLACEMENT)

FIVE (5) YEAR – LIMITED WARRANTY

The manufacturer will provide, without charge, a replacement canning element for any canning element which has a defect in material or workmanship during the first five (5) years after the date of the original retail purchase. This warranty extends to any owner during the five (5) year warranty period when the appliance is located in the United States. Labor charges, if any, are NOT covered by this warranty.

(Warranty Continued On Back)

WHAT IS NOT COVERED BY THIS WARRANTY

1. Conditions and damages resulting from any of the following:
 - a. Improper installation, delivery, or maintenance.
 - b. Any repair, modification, alteration or adjustment not authorized by the manufacturer, or an authorized servicer.
 - c. Misuse, abuse, accidents or unreasonable use.
 - d. Incorrect electrical current, voltage or supply.
 - e. Improper setting of any control.
2. Canning chrome drip bowl
3. Products purchased for commercial or industrial use.
4. The cost of service or service call to:
 - a. Correct installation errors.
 - b. Instruct the consumer on the proper use of the product.
 - c. Transport the canning element to a servicer.
5. **CONSEQUENTIAL OR INCIDENTAL DAMAGES SUSTAINED BY ANY PERSON AS A RESULT OF ANY BREACH OF THIS WARRANTY.** Some states do not allow the exclusion or limitation of consequential or incidental damages, so the above exclusion may not apply to you.

HOW TO RECEIVE WARRANTY SERVICE

1. Contact the dealer from whom you purchased the canning element or any authorized servicer to receive warranty service under these warranties.
2. Should you not receive satisfactory warranty service from your local servicer, contact:

Maytag Customer Service
P.O. Box 2370
Cleveland, TN 37320-2370

3. Have the following information available when requesting warranty service:
 - Your name, address and telephone number.
 - The model number of your canning element.
 - The name and address of your dealer or servicer.
 - The purchase date of your canning element.
 - A clear description of the problem.

The warranty described above is the only written or express warranty given by the manufacturer. No one is authorized to increase, alter, or enlarge the manufacturer's responsibilities or obligations under this warranty. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.