


GRILL COVER

Model A340



USE:

Your grill cover is built of textured steel with wood handles . . . and makes an attractive cover for the grill section of your grill-range when it is not in use.

DO NOT use the grill cover over a heated grill . . . let it cool before putting the cover in place.

REMOVE cover — always — before heating grill! Since a hot grill cover would not appear hot, this could create accidental burns should it be touched. Too, heating the grill cover could damage the finish and the wood handles.

CLEANING

Your grill cover may be easily cleaned with a damp cloth and detergent. Rinse clean after washing. DO NOT clean in dishwasher as this can damage the wood handles.

In many cases normal household spray cleaner may be utilized to clean the grill cover. Vegetable oil or spray wax may also be used to preserve the wood handles.

Note: While the black finish is very durable, care should be taken to avoid setting material on the surface that could cause scratches . . . or setting extremely hot containers on the surface that could mar or discolor the finish. Remember, it is an attractive cover . . . and proper care will keep it that way!



3035 SHADELAND • INDIANAPOLIS, IN 46226-0901