

JENN-AIR



Use and Care Insert

Gas Grill Accessory

MODEL AG150

Installing the Grill

The grill accessory includes a grill burner, two black grill grates, and a black air grille. The grill can only be installed on the left side of your cooktop.

1. Before installing grill components, be certain control knobs are in the OFF position.
2. Remove the surface burner module.
3. Position the grill burner with the mixer tube openings towards the orifices. Slide the burner towards the orifices until igniter is in between front and rear grill sections. Lower into place until side openings are resting on the burner support pins.

Note: Before using the grill for the first time, heat the E-ven Heat™ grill burner to remove the black protective shipping coating. Heat the grill on **Hi** for 10 minutes and use the vent system to remove any additional smoke during cooling. When the E-ven Heat grill burner is a dull black, it is ready to use.

4. Place the grill grates on the top of the cooktop.
5. Replace the white air grille with the black air grille to prevent possible discoloration of the white air grille.

Usage, Cleaning, and Safety Precautions

NOTE: For safety precautions, usage and cleaning information, please refer to the use and care manual (Part No. 204782) packaged with your cooktop.